

GEMÜ 44A0

Multi-functional valve actuation

EN

Operating instructions



All rights including copyrights or industrial property rights are expressly reserved.

Keep the document for future reference.

© GEMÜ Gebr. Müller Apparatebau GmbH & Co. KG
02.12.2025

Quick commissioning

⚠ CAUTION



Hazardous situation!

- ▶ Risk of injury or damage possible
- For correct commissioning, the product must be calibrated to the process valve via the initialization process.
- During this commissioning, the valve is automatically opened and closed several times. It must therefore be ensured in advance that this does not lead to a dangerous situation.

NOTICE

Operating errors!

- Prior to commissioning, familiarize yourself with the operation of the product.

NOTICE

Incorrect initialization!

- Always carry out initialization without operating medium pressure on the process valve. Carry out initialization of the process valve in neutral position (NO/NC).

NOTICE

- For delivery of the product assembled on a valve at the factory, the complete construction is already ready for operation at a control pressure of 5.5 to 6 bar without operating pressure. A reinitialization is recommended if the plant is operated with a different control pressure or if the mechanical end positions have been changed (e.g. seal replacement on the valve or actuator replacement). The initialization is retained even in the event of voltage cutoff.

NOTICE

- For delivery of the product without default setting (e.g. for delivery without valve) initialization must be carried out once for correct operation. This initialization must be repeated every time that the process valve is changed (e.g. seal replacement or actuator replacement).

NOTICE

Positioner without wireless interface design!

- ▶ To carry out the initialization required for operation, IO-Link must be used since the optional app connection cannot be used.
Alternatively, a Bluetooth module can be installed temporarily for this action (see chapter "Assembly and installation of the Bluetooth module type E1B0"), but this must be ordered or available at least once.
1. Mount the product on the process valve mechanically.
 2. Connect the product pneumatically: Supply the marked connection with pneumatic control air supply (max. 7 bar).
 3. Connect the product electrically.
 - ⇒ Connect the supply voltage 24 V DC (or 18 to 30 V DC) – pin 1: Uv+; pin 3: GND (high-visibility LED display briefly flashes turquoise during device start-up)
 - ⇒ If delivered without a valve: High-visibility LED display indicates a warning ("No initialization"). LED flashes alternately orange/red
 4. Carry out automatic initialization (this differs depending on whether OPEN/CLOSE actuation or a positioner is used):
 - ⇒ The initialization can be started via ASi-5 by toggling process data output bit 2 (Master -> Device) or via the app.
- **OPEN/CLOSE actuation:**
The end positions are determined automatically as soon as the valve moves. The valve is therefore ready for operation directly, reports the end positions back after an initial movement cycle, and shows these via the LED display (except when the "Detection of end positions mode" does not correspond to "Autonomous"). In this case, initialization must be triggered with a command (IO-Link or app).
The process valve can be controlled via process data output bit 0 (Master -> Device) (Logic 0 = vented / Logic 1 = pressurized).

- **Positioner:**

Trigger initialization with a command (IO-Link or app).

5. The initialization phase lasts for a few minutes, during which the process valve is opened and closed several times. The high-visibility LED display flashes alternately yellow/white for the duration. The initialization process is then ended automatically.
6. The product is ready for operation and reacts to specified signals (IO-Link communication required or app operation).

Contents

1 General information	6	14 Operation	28
1.1 Information	6	14.1 Bluetooth interface	29
1.2 Symbols used	6	14.2 Basic operation of the app	30
1.3 Warning notes	6	14.3 Sensor system for status monitoring	31
2 Safety information	7	14.4 Integrated diagnostic functions	31
3 Product description	7	14.4.1 Integrated diagnostic functions (OPEN/CLOSE actuation device function)	31
3.1 Construction	7	14.4.2 Integrated diagnostic functions (po- sitioner device function)	32
3.2 High visibility LEDs	7	15 Specific data relating to IO-Link	33
3.3 Description	9	16 Process data	33
3.4 Function	9	17 IO-Link system commands	35
3.6 Digital product label	10	18 Parameter list (IO-Link and GEMÜ app)	37
4 Intended use	10	19 Troubleshooting	55
5 Order data	11	20 ISDU errors	62
5.1 Order codes	11	21 Inspection and maintenance	64
5.2 Order example	12	22 Disassembly	64
6 Technical data	13	22.1 Combi switchbox disassembly	64
6.1 Medium	13	22.2 Type E1B0 Bluetooth module disassembly ..	64
6.2 Temperature	13	23 Disposal	66
6.3 Pressure	13	24 Returns	66
6.4 Product compliance	13	25 EU Declaration of Conformity	67
6.5 Mechanical data	13		
6.6 Operating conditions	14		
6.7 Electrical data	14		
6.7.1 Wireless-specific parameters	15		
6.7.2 Positioner data (positioner device function)	15		
6.7.3 Sensor system for status monitor- ing	17		
7 Dimensions	18		
8 Manufacturer's information	19		
8.1 Delivery	19		
8.2 Packaging	19		
8.3 Transport	19		
8.4 Storage	19		
9 Assembly and installation	19		
9.1 Preparations for installing the valve (linear actuator)	19		
9.2 Combi switchbox installation	20		
9.2.1 Installing combi switchbox size 1 ...	20		
9.2.2 Installing combi switchbox size 2 and 3	21		
9.3 Assembly and installation of the type E1B0 Bluetooth module	22		
9.3.1 Preparations for installation	22		
9.3.2 Installing the type E1B0 Bluetooth module	22		
10 Electrical connection	24		
11 Pneumatic connection	24		
12 Error response	26		
13 Commissioning	26		
13.1 Initialization	26		
13.1.1 Autonomous end position process/ end position tracking	27		
13.1.2 Classic initialization process	27		
13.2 Commissioning the type E1B0 Bluetooth module	28		

1 General information

1.1 Information

- The descriptions and instructions apply to the standard versions. For special versions not described in this document the basic information contained herein applies in combination with any additional special documentation.
- Correct installation, operation, maintenance and repair work ensure faultless operation of the product.
- Should there be any doubts or misunderstandings, the German version is the authoritative document.
- Contact us at the address on the last page for staff training information.

1.2 Symbols used

The following symbols are used in this document:

Symbol	Meaning
●	Tasks to be performed
►	Response(s) to tasks
–	Lists

1.3 Warning notes

Wherever possible, warning notes are organized according to the following scheme:

SIGNAL WORD	
Possible symbol for the specific danger	Type and source of the danger ► Possible consequences in case of non-compliance ● Measures for avoiding danger

Warning notes are always labelled with a signal word and sometimes also with a symbol for the specific danger.

The following signal words and danger levels are used:

 DANGER	
	Imminent danger! ► Non-observance can cause death or severe injury
 WARNING	
	Potentially dangerous situation! ► Non-observance can cause death or severe injury
 CAUTION	
	Potentially dangerous situation! ► Non-observance can cause moderate to light injury

NOTICE



Potentially dangerous situation!

- Non-observance can cause damage to property

The following symbols for the specific dangers can be used within a warning note:

Symbol	Meaning
	Danger of explosion!
	Possible risk of crushing by the indicator spindle!
	Risk of crushing!
	Risk of cutting injuries!
	Electrostatic discharge!
	Hot product!
	Safety notice!
	The equipment is subject to pressure!
	Hot components!
	Minor or moderate injury from a falling product!

2 Safety information

The safety information in this document refers only to an individual product. Potentially dangerous conditions can arise in combination with other plant components, which need to be considered on the basis of a risk analysis. The operator is responsible for the production of the risk analysis and for compliance with the resulting precautionary measures and regional safety regulations.

The document contains fundamental safety information that must be observed during commissioning, operation and maintenance. Non-compliance with these instructions may cause:

- Personal hazard due to electrical, mechanical and chemical effects
- Hazard to nearby equipment
- Failure of important functions
- Hazard to the environment due to the leakage of dangerous materials

The safety information does not take into account:

- Unexpected incidents and events, which may occur during installation, operation and maintenance
- Local safety regulations which must be adhered to by the operator and by any additional installation personnel

Prior to commissioning:

1. Transport and store the product correctly.
2. Do not paint the bolts and plastic parts of the product.
3. Carry out installation and commissioning using trained personnel.
4. Provide adequate training for installation and operating personnel.
5. Ensure that the contents of the document have been fully understood by the responsible personnel.
6. Define the areas of responsibility.
7. Observe the safety data sheets.
8. Observe the safety regulations for the media used.

During operation:

9. Keep this document available at the place of use.
10. Observe the safety information.
11. Operate the product in accordance with this document.
12. Operate the product in accordance with the specifications.
13. Maintain the product correctly.
14. Do not carry out any maintenance work and repairs not described in this document without consulting the manufacturer first.

In cases of uncertainty:

15. Consult the nearest GEMÜ sales office.

3 Product description

3.1 Construction

Actuator **A** must be ordered separately.



Item	Name	Materials
1	Housing cover, black	PC
2	Housing ventilation	ePTFE
3	LED signalling window	PC
4	Transparent cap	PC
5	Electrical threaded connection	SS/1.4305
6	Pneumatic connectors	SS/1.4305
7	Seal	FKM
8	Type E1B0 Bluetooth module (optional) with slider cover	-
-	Mounting plate (only size 1)	Anodized aluminium

3.2 High visibility LEDs

As well as the electrical position indicator and error output, a visual signal of the various operating conditions is emitted by high visibility LEDs **1** integrated into the housing. The LEDs are arranged so that two light bands integrated on the side are illuminated, making the condition also apparent from a distance. The following conditions are illustrated here:



Valve position indicator for OPEN/CLOSE actuation device function (combi switchbox) ¹⁾

Colour of high visibility LEDs		Function
Standard	Inversed ²⁾	
Green	Orange	Process valve in OPEN position
Orange	Green	Process valve in CLOSED position
Flashing green	Flashing orange	Movement of process valve in OPEN direction
Flashing orange	Flashing green	Movement of process valve in CLOSED direction

Valve position indicator for positioner device function ¹⁾

Colour of high visibility LEDs		Function
Standard	Inversed ²⁾	
Orange (100% brightness)	Green (100% brightness)	Process valve in CLOSED position
Green 25% brightness	Orange 25% brightness	Process valve ≤ 25% open
Green 50% brightness	Orange 50% brightness	Process valve ≤ 50% open
Green 75% brightness	Orange 75% brightness	Process valve ≤ 75% open
Green 100% brightness	Orange 100% brightness	Process valve > 75% open

¹⁾ The valve position indicator can be dimmed or deactivated via parameters.

²⁾ Inverted display can be activated via parameters

Status indication of all device functions

Colour of high-visibility LEDs	Function
Standard	
Flashing yellow/white	Initialization active
Flashing white	Localization active
Flashing orange/red	General warning active
Flashing red	General error active
Flashing yellow/turquoise	Maintenance required
Flashing blue (briefly)	Wireless connection established
Flashing purple/green	Internal update process active
Flashing turquoise (briefly)	Device start
Lit up red (permanently)	Serious error (device faulty)

3.3 Description

Independent of the actuator size, the GEMÜ 44A0 multi-functional valve actuation, as an automation module, is compatible with all pneumatically operated process valves with single acting linear actuator of the new valve generation. Depending on the order variant and the set device functions, the connected process valves can be controlled conventionally open/closed (combi switchbox) or the valve position can be precisely controlled (positioner). Contactless position detection determines the valve position precisely, reliably and without being subject to wear. The current valve position is displayed via high visibility LEDs, and fed back via electrical signals. In addition to this, there is an integrated mechanical position indicator. Modern communication interfaces, an integrated sensor system and the GEMÜ app operating option are all features that characterize this innovative product.

3.4 Function

GEMÜ 44A0 is an intelligent, multi-functional combi switchbox for mounting on pneumatic actuators. The product is directly mounted on the actuator. An integrated digital and contactless position sensor system measures the current valve position via a magnetic spindle that is positively connected to the actuator spindle and reports this position to the electronic system of the product.

NOTICE

- In the order version with code C = positioner, the device function can be changed over between OPEN/CLOSE actuation and the positioner via parameter settings. This means that the same device can be used to implement OPEN/CLOSE applications as well as control applications.
- The order version code B = basic is limited to OPEN/CLOSE actuation.

NOTICE

- The "Extended OPEN/CLOSE actuation" device function, which can be selected, is currently identical to "OPEN/CLOSE actuation".

OPEN/CLOSE actuation device function

(order version code B = basic):

The pneumatic actuator is actuated via integrated pilot valves. Should the valve be opened, the internally installed pilot valves control the pneumatic actuator accordingly. The magnetic spindle in the combi switchbox consequently moves upwards and indicates that the valve is OPEN using the high visibility LEDs and communication interface. Should the valve be closed, the internally installed pilot valves control the pneumatic actuator accordingly. The magnetic spindle simultaneously moves downwards and indicates that the valve is CLOSED using the high visibility LEDs and communication interface.


Positioner device function

(order version code C = positioner):

The electronic system compares the actual value of the valve (valve position) with the set value specified and readjusts the valve accordingly in the event of a control error. The currently determined valve position is signalled via the high visibility LEDs and output via the communication interface. For correct operation, the positioner must first be calibrated (initialized) to the connected process valve. This is done by an automatic initialization function, which can be started via the communication interface or the GEMÜ app. Once this has been carried out, the positioner automatically switches to the normal operating mode and reacts to the set value specified via the communication interface.

3.5 Product label

The product label is located on the side of the product.
Product label data (example):



The date of manufacture is encoded in the production ID and can be obtained from GEMÜ.


NOTICE

Device version

- The device version can be used to quickly draw conclusions about the firmware used or the basic device status. For full details on specific product composition, the firmware and hardware versions must be read out electronically via the communication interface.

Device version	Firmware version	Effective from	Changes
01	V1.1.0.0	07/2025	-

3.6 Digital product label



The product has a digital name plate. The digital name plate allows the product to be uniquely identified worldwide and, in addition to the classic name plate data, enables lots of additional product-related information to be called up digitally.

Using the digital name plate, GEMÜ fulfils the requirements of DIN SPEC 91406 on the automatic identification of physical objects.

The digital name plate contains a readable 12-digit serial number in addition to the QR code.

For products operated via the GEMÜ App, the last four digits of the 12-digit serial number are used as the Bluetooth names for the product in its default state (e.g. 8977 here). The 12-digit serial number is used as the password for connecting to the product in its default state.

It is recommended that the Bluetooth name and password for the Bluetooth connection are changed (further information is provided in the "Operation" chapter under "Bluetooth interface" (see "Bluetooth interface", page 29).

4 Intended use

⚠ DANGER



Danger of explosion!

- Risk of death or severe injury
- Do **not** use the product in potentially explosive zones.

⚠ WARNING

Improper use of the product!

- Risk of severe injury or death
- Manufacturer liability and guarantee will be void.
- Only use the product in accordance with the operating conditions specified in the contract documentation and in this document.

The product is not intended for use in potentially explosive areas.

The product with integrated pilot valves is designed to be fitted to GEMÜ valves with linear actuators of the new platform generation. The product has a microprocessor-controlled intelligent position sensor as well as a digital, contactless position sensor system. The valve end positions and the operating conditions can be monitored via the electrical connections. The pneumatic actuator is directly operated and controlled by means of the integrated pilot valves. Any other use or use above and beyond this is not permitted. GEMÜ shall not be liable for any consequential damage. The user alone bears the risk.

1. Use the product in accordance with the technical data.
2. Take care to ensure that the BLE stick is used as intended!

5 Order data

The order data provide an overview of standard configurations.

Please check the availability before ordering. Other configurations available on request.

Note: If there are restrictions on the customer or on the system side which prohibit the use of a Bluetooth interface, we recommend using an order variant with a deactivated Bluetooth interface or without a Bluetooth interface.

For designs with a Bluetooth interface, the option also exists to deactivate the interface via parameters independently later or to uninstall the type E1B0 Bluetooth module.

For designs without a Bluetooth interface, the option also exists to retrofit the interface independently later.

Note:

- Basic device version (code B) = OPEN/CLOSE valve actuation (combi switchbox)
- Positioner device version (code C) contains both the positioner function and OPEN/CLOSE actuation (adjustable via parameter)

Order codes

1 TYPE	Code
Multi-functional valve actuation	44A0
2 Electrical interface	Code
IO-Link	IO
3 Action	Code
Single acting	1
4 Direction of movement	Code
Linear	L
5 Device version	Code
Basic	B
Positioner	C
6 Interface/size	Code
Size 1	1
Size 2	2
Size 3	3
7 Body material	Code
Plastic	P
8 Options	Code
Without	0
9 Electrical connection	Code
M12 connector	1
10 Air supply	Code
Integrated	I
11 Wireless interface	Code
Bluetooth	B
None	0
12 Local User Interface	Code
LEDs	L
13 Mechanical option	Code
Without	0

Order example

Ordering option	Code	Description
1 TYPE	44A0	Multi-functional valve actuation
2 Electrical interface	OK	IO-Link
3 Action	1	Single acting
4 Direction of movement	L	Linear
5 Device version	B	Basic
6 Interface/size	2	Size 2
7 Body material	P	Plastic
8 Options	0	Without
9 Electrical connection	1	M12 connector
10 Air supply	I	Integrated
11 Wireless interface	B	Bluetooth
12 Local User Interface	L	LEDs
13 Mechanical option	0	Without

6 Technical data

6.1 Medium

Working medium:	Compressed air and inert gases
Dust content:	Class 3, max. particle size 5 µm, max. particle density 5 mg/m³
Pressure dew point:	Class 4, max. pressure dew point +3 °C
Oil content:	Class 5, max. oil concentration 25 mg/m³ Quality classes to DIN ISO 8573-1

6.2 Temperature

Ambient temperature:	-10 – 60 °C
Control medium temperature:	-20 – 60 °C
Storage temperature:	-20 – 70 °C

6.3 Pressure

Control pressure:	0.5 max. 7 bar The applied pressure must not exceed the maximum control pressure of the process valve. (If the measured control pressure is ≤ 1.0 bar, a warning is issued as standard to indicate that the control pressure has not been reached, and if it is ≥ 7.1 bar, a warning is issued to indicate that the control pressure has been exceeded. The warning thresholds can be changed.)
Air consumption:	0 NI/min (when idle)

6.4 Product compliance

EMC Directive:	2014/30/EU
RoHS Directive:	2011/65/EU
Approval:	Fieldbus/communication: IO-Link specification V1.1.4

6.5 Mechanical data

Installation position:	Optional
Weight:	Size 1: 240 g Size 2: 262 g Size 3: 798 g

Travel sensor:		Size 1 and 2	Size 3
	Minimum stroke ¹⁾ :	2.0 mm	5.0 mm
	Maximum stroke ²⁾ :	29.0 mm	45.0 mm
	Correlation between travel sensor spindle/valve position ³⁾	Retracted (top) ± 100% (valve open) Extended (bottom) ± 0% (valve closed)	
	¹⁾ Relevant for successful initialization		
	²⁾ Corresponds to the linearized stroke range		
³⁾ Relative to the setting value 0 = deactivated of the “Inversion of travel sensor signal” parameter. If the inversion of the travel sensor signal is activated, the correlation is correspondingly inverted.			

6.6 Operating conditions

Ambient conditions:	Use indoors and outdoors Dry and wet environments
Height:	Up to 2000 m (above sea level)
Relative air humidity:	0–100%

Protection class:	Single device as supplied	Mounted to actuator
	Unintended operating condition	IP 65

Degree of contamination: 4 (pollution degree)

6.7 Electrical data

Supply voltage U_v : 18 - 30 V DC (in accordance with IO-Link specification)

Duty cycle: Continuous duty


Reverse polarity protection: yes

Electrical protection class: III

Current consumption: Maximum 135 mA

Electrical connection type: 1 x 5-pin M12 plug (A-coded)

Switching characteristic:



Switch points in data in percent of the programmed stroke, with reference to the lower end position (0%)

Switch points:

	Size 1 and 2	Size 3
Switch point CLOSED	Default setting: 12% (adjustable from 0–90%)	
Switch point OPEN	Default setting: 75% (adjustable from 10–100%)	
Min. switch point CLOSED	0.8 mm	1.2 mm
Min. switch point OPEN	0.5 mm	0.75 mm
Switching hysteresis	2% (relative to the initialized range upstream of the respective switch point)	

If the percentage switch points dependent on the programmed stroke are less than the permissible min. switch points, the min. switch points apply automatically. The min. switch points refer to the value before achieving the initialized end position values for the respective item. For example, the CLOSED end position is output at the very latest from 0.8 or 1.2 mm before reaching the initialized end position value of the CLOSED position. The detection and feedback of end positions can also take place earlier (dependent on the stroke) due to the set percentage value of switch point OPEN or CLOSED. A difference of at least 10% must be maintained between the switch point settings.

Travel sensor:

Linearity: < 0.6%

Repeatability: < 0.3%

- These values refer to properties including influences of a reference interference field in the form of an identical device with the smallest possible distance to each other.

- The data can only be guaranteed and complied with within the defined functional stroke range of the valves provided. These are a maximum of 25 mm for size 1 and size 2 and a maximum of 41 mm for size 3.

Interface:

	Bluetooth Low Energy (only with integrated wireless interface)	IO-Link
Function	Parameterization, configuration, diagnostics and operation	Parameterization, configuration, diagnostics and operation
Prerequisite	Compatible smartphone/tablet with Android or iOS ¹⁾ - Apple iOS: Version 16.6 or higher - Android: Version 8.0 ("Oreo") or higher - Bluetooth 4.0 LE or newer	IO-Link master spec. 1.1
Version	Bluetooth 5.4 (Low Energy)	IO-Link spec. V1.1.4

¹⁾ The compatible GEMÜ app can be downloaded in the respective stores (Apple App Store or Google Play Store).

6.7.1 Wireless-specific parameters


Technology: Bluetooth Low Energy (only possible in conjunction with the GEMÜ app)

Frequency: 2.4 GHz (2.4–2.4835 GHz)

Output power: Max. 11.2 dBm

6.7.2 Positioner data (positioner device function)

Note: The following diagram is valid for valves with a standard assignment of the spindle position to the valve position.
(See section "Mechanical data, correlation between travel sensor spindle/valve position")

Control diagram:

Note: The control diagram shown here relates to the parameter values at the factory. The control diagram can be influenced/changed by multiple parameters (for example, "Inversion of the travel sensor signal" and/or "Control characteristic")

The digital electro-pneumatic positioner automatically detects the control function of the valve during initialization: Normally open (NO) or normally closed (NC).

For the 0% signal specification, the position of the valve is closed.

The close tight function that is integrated as standard ensures that the valve is moved completely to the end position when the signal "Open valve" or "Close valve" is specified.

Positioner information:

System deviation:	1% default setting
(dead zone)	0.1–25.0% (can be set at fixed values)
	0.1–5.0% (adaptive self-adjustment)
Parameterization:	Via IO-Link or app
Initialization:	Automatic, via IO-Link or app
Close tight function:	Closed: Set value $\leq 0.5\%$
	Open: Set value $\geq 99.5\%$
	(alterable via parameter)


6.7.3 Sensor system for status monitoring

Value	Value range	Sensor resolution	Deviation	Typical deviation.	Long-term stability
Internal temperature	-40 to 100 °C	0.016 °C	$\pm 1.60 \text{ °C}^{1)}$	$\pm 0.20 \text{ °C}^{1)}$	$< \pm 0.02 \text{ °C/year}$
Internal humidity	0 to 100%	0.03%	$\pm 3.5\%$ between 20 to 80% $\pm 6.5\%$ between 0 to 100%	$\pm 2\%$ between 20 to 80% $\pm 3.5\%$ between 0 to 100%	$\pm 0.25\%/year$
Internal pressure	260 to 1260 mbar	24 bit	$\pm 1.0 \text{ mbar}$	$\pm 0.1 \text{ mbar}$	-
Control air supply pressure	0 to 30 bar	1.31 mbar	$\pm 110 \text{ mbar}$	$\pm 30 \text{ mbar}$	$\pm 30 \text{ mbar/year}$
Actuator chamber pressure	0 to 30 bar	1.31 mbar	$\pm 110 \text{ mbar}$	$\pm 30 \text{ mbar}$	$\pm 30 \text{ mbar/year}$
Installation position (in two directions)	-180° to 180°	16 bit	- ²⁾	$\pm 3.1^\circ$ ²⁾	-
Acceleration (in three axes)	-156.96 m/s ² to 156.96 m/s ²	16 bit	$\pm 1.48 \text{ m/s}^2$	$\pm 0.52 \text{ m/s}^2$	-
Current consumption	0 to 375 mA	16 bit	$\pm 3.0 \text{ mA}$	$\pm 0.5 \text{ mA}$	-
Supply voltage	0 to 36 V	16 bit	$\pm 0.5 \text{ V}$	$\pm 0.05 \text{ V}$	-

¹⁾ The value is measured on the inside of the housing with the corresponding influences of the device electronics (e.g. heating).

²⁾ The data refers to a vibration-free status. In the case of vibrations, the deviation can be significantly greater or a value can no longer be determined.

7 Dimensions



	Ø A	B	C	E	F	G
Size 1	65.0	42.0	20.4	85.6	86.3	75.7
Size 2	65.0	42.0	20.4	75.6	76.3	65.7
Size 3	88.9	61.0	26.7	100.7	109.1	90.8

BG = size
Dimensions in mm

8 Manufacturer's information

8.1 Delivery

- Check that all parts are present and check for any damage immediately upon receipt.

The product's performance is tested at the factory. The scope of delivery is apparent from the dispatch documents and the design from the order number.

8.2 Packaging

The product is packaged in a cardboard box which can be recycled as paper.

8.3 Transport


1. Only transport the product by suitable means. Do not drop. Handle carefully.
2. After the installation dispose of transport packaging material according to relevant local or national disposal regulations / environmental protection laws.

8.4 Storage

1. Store the product free from dust and moisture in its original packaging.
2. Avoid UV rays and direct sunlight.
3. Do not exceed the maximum storage temperature (see chapter "Technical data").
4. Do not store solvents, chemicals, acids, fuels or similar fluids in the same room as GEMÜ products and their spare parts.
5. Close the compressed air connections with protection caps or sealing plugs.

9 Assembly and installation

9.1 Preparations for installing the valve (linear actuator)



	Tools:		
	Actuator size 1	Actuator size 2 and 3	Actuator size 4.5 and 6
Open-end wrench 1:	Wrench size 13	Wrench size 17	Wrench size 24
Open-end wrench 2:	Depending on pneumatic connection used		
Allen key:	Wrench size 3	Wrench size 4	Wrench size 6

1. Move actuator **40** into zero position (actuator vented).
⇒ Ensure that the actuator is **depressurized!**
2. Remove transparent cap **23** (open-end wrench 1).
3. Remove indicator spindle **41** (Allen key).
4. Remove pneumatic connections **42** (open-end wrench 2).

9.2 Combi switchbox installation

WARNING



Possible risk of crushing by the indicator spindle!

- Injury possible, because the actuator must be pressurised in order to reach the flat (only NC drives).
- Do not reach into the operating range of the indicator spindle.

NOTICE

Leak-tightness of housing affected.

- If the contact surface of the actuator has previously been damaged, the leak-tightness of the housing cannot be ensured.
- Check the contact surfaces of the actuator before installation and ensure they are undamaged. Contact GEMÜ if damage can be detected.

NOTICE

Contamination and humidity!

- If there is dirt and/or humidity on the inside of the actuator or on the contact surfaces of the actuator, it can cause functional impairment or device failure.
- Check and ensure that there is no humidity and/or dirt on the inside or on the contact surfaces of the actuator, or remove any such before assembly.

NOTICE

Leak-tightness of the product adversely affected!


- In the case of unclean inserted or seated seals (14 or 5) both the housing seal and the pneumatic tightness on the actuator can be adversely affected.
- Check and ensure that the seals are complete and that they are seated correctly in the intended position.

NOTICE

The pneumatic connections also act as a fixture to the actuator!

- Before performing any work on the product, depressurize the pneumatic connection.

9.2.1 Installing combi switchbox size 1




Tools:

Open-end wrench 1:	Wrench size 4
Allen key 2:	Wrench size 10
Allen key 3:	Wrench size 6

1. Move actuator **A** into zero position (actuator vented).
⇒ Ensure that the actuator is depressurized.
2. Carefully insert the seal **26** into the groove provided for it in the mounting plate **25**, and check that it is seated correctly.
3. Align the mounting plate **25** and the inserted seal **26** with the actuator **A** control air connectors of the same name.
⇒ (Marking of mounting plate "1" with control air connector actuator "1" and "2" with "2").
4. Connect mounting plate **25** (if necessary, gently twist until the collars of the mounting plate **25** engage in the control air connectors of actuator **A**) and use collar screw **24** to fasten it to the central thread of actuator **A** and tighten (size 10 Allen key – torque 15 Nm).
5. Screw the operating bush **111** into actuator **A** and tighten it to the wrench surface (size 4 open-end wrench) (torque of 2 to 2.5 Nm – the tightening torque is reached if the piston is also turned).
6. Carefully insert the moulded seal **14** into the groove provided for it at the bottom of the housing of the product **1** and check that it is seated correctly.
7. Check and ensure that the sealing rings **5** are seated correctly on both stud bolts.
8. Align product **1**. **Please note:** The orientation is dependent on the control function of the actuator.
⇒ Control function 1 (normally closed): Actuator control air connector = 1 // → product control air connector **with marking**.
⇒ Control function 2 (normally open): Actuator control air connector = 2 // → product control air connector **with marking**.
9. Alternately screw in the stud bolts **3** and **8** in the correct orientation (size 6 Allen key) and tighten them (10 Nm torque).
⇒ **Note:** The hexagon socket screw drive is incorporated into the stud bolts. As a result, an Allen key with a shaft length of at least 16 mm is required. A short bit insert cannot be used.
10. Make the pneumatic and electrical connection.

9.2.2 Installing combi switchbox size 2 and 3



Tools:

Open-end wrench:	Wrench size 8
Allen key 2:	Wrench size 6

1. Move actuator **A** into zero position (actuator vented).
⇒ Ensure that the actuator is **depressurized!**
2. Screw the operating bush **20** into the pneumatic actuator and tighten it to 2.5–3 Nm (size 8 open-end wrench).
3. Carefully insert the moulded seal **14** into the groove provided for it at the bottom of the housing of the product, and check that it is seated correctly.
4. Check and ensure that the sealing rings **5** are seated correctly on both stud bolts.
5. Align the product. **Please note:** The orientation is dependent on the control function of the actuator.
⇒ Control function 1 (normally closed): Actuator control air connector = **1** // → combi switchbox control air connector with marking.
⇒ Control function 2 (normally open): Actuator control air connector = **2** // → combi switchbox control air connector with marking.
6. Alternately screw in the stud bolts **3** and **8** in the correct orientation (size 6 Allen key) and carefully tighten them (10 Nm torque).
⇒ **Note:** The hexagon socket screw drive is incorporated into the stud bolts. As a result, an Allen key with a shaft length of at least 16 mm (size 2) or 20 mm (size 3) is required. A short bit insert generally cannot be used.
7. Make the pneumatic and electrical connection.

9.3 Assembly and installation of the type E1B0 Bluetooth module

Note: This chapter is only relevant for later installation or a replacement.

Observe the separate documentation for the type E1B0 Bluetooth module.

⚠ CAUTION



Risk of crushing!

- ▶ Pinching of fingers during disassembly/installation of the type E1B0 Bluetooth module in the slider cover or of the type E1B0 Bluetooth module with a slider cover in the housing
- Installation work must only be performed by trained personnel.
- Wear suitable protective gear.

⚠ CAUTION



Risk of cutting injuries!

- ▶ Risk of cutting injuries due to sharp edges, corners or protruding parts
- Installation and disassembly work must only be performed by trained personnel.
- Use suitable cutting protection.

NOTICE

Damage to the product!

- Ensure that the module is installed/disassembled correctly and pay attention to any damage to the product.

NOTICE



Electrostatic discharge!


- ▶ Destruction of electronic components.
- Take the necessary ESD safety precautions during installation of the product.

9.3.1 Preparations for installation


- Ensure ESD protection
- Prevent foreign matter from penetrating into the device's open slot
- Avoid mechanical stress (for example, vibrations)
- Ensure that the environment is clean
- Check for moisture prior to installation
- Disconnect the product from the power supply

9.3.2 Installing the type E1B0 Bluetooth module

Check all parts for damage, contaminants and moisture prior to installation. The module must only be installed by trained personnel. To prevent damage, suitable precautionary measures must be provided for with regard to ESD.





1. Undo the screw 1 (hexagon socket, size 1.5) of the slider cover 2 (the screw is secured against falling out of the slider cover 2 by a circlip).



2. Remove the slider cover 2 with the screw 1 from the housing 4.

⇒ To accomplish this, carefully grip the screw head with small pliers (e.g. needle-nose pliers) and pull it out vertically upwards. Take care not to tilt or damage the part.





3. Insert the type E1B0 Bluetooth module **3** into the slider cover **2** until the snap hook **5** clicks into position.
4. Ensure that the type E1B0 Bluetooth module **3** is installed correctly!
 - ⇒ The pins of the type E1B0 Bluetooth module **3** in the slider cover **2** should be facing forwards and aligned towards the snap hook **5** and recessed handle **6**.
5. Reinstall the slider cover **2** with the type E1B0 Bluetooth module **3** fitted back into the housing **4** and tighten with a screw **1** (hand tight, maximum torque 0.4 Nm, size 1.5 hexagon socket).

10 Electrical connection

NOTICE

It is possible to touch the electronic system when the product is dismantled!


- When disassembling the product, disconnect the power supply.

NOTICE

Risk of damage!

- Product failure
- Connector cannot be aligned.
- The connector must be protected from turning.


IO-Link



	Description
1	Uv+, 24 V DC, supply voltage
2	n.c.*
3	Uv-, GND
4	C/Q IO-Link
5	n.c.*

* Pins 2 and 5 are not relevant for the function and may therefore be populated (visible) or not populated (not present).

11 Pneumatic connection



Connection	Marking	Designation	Connection size
1	Marking on the connection	Air supply connection (with integrated control pressure detection)	Size 1 and size 2: G1/8 Size 3: G1/4
2	(without marking)	Venting connection and process valve spring chamber ventilation	Size 1 and size 2: G1/8 Size 3: G1/4

The product comes with two pneumatic connections (for commercially available 6x4 mm pneumatic tubing) and a venting plug as standard. These are provided as follows:

Control function of valve actuator	Connector 1	Connector 2
Single acting (NO or NC) (see figure at the top right)	Pneumatic connection	Venting plug*
* With piped air outlet: Pneumatic connection. The venting plug is not suitable for IP 67 and is not recommended for damp ambient conditions.		

11.1 Information for use in damp conditions

The following information is intended to help when installing and operating the product in damp conditions.

1. Cables and pipework must be laid so that condensate or rain water that remains on the pipework/cables cannot enter the screw fittings of the product's M12 plugs.
2. Check that all cable glands of the M12 plugs and the fittings are mechanically secured.
3. In case of doubt, the housing protection class should be increased with an exhaust air duct to areas free from moisture (only relevant for single acting process valves). To accomplish this, equip the provided venting connection (spring chamber ventilation) with suitable pneumatic connections to discharge the exhaust air in a targeted manner via a pneumatic line. Ensure that the ventilation line is always depressurized, that it is not operated with throttles, filters or similar components. The ventilation lines must be laid in such a way that moisture cannot flow back.

12 Error response

Error	Process valve
Electrical power supply failure or minimum supply voltage not reached	Vented
Pneumatic compressed air supply failure or minimum control pressure not reached	Vented
Malfunctions detected by the software in the Error category (see chapter "Troubleshooting")	Set error position ("Error position" parameter) is performed. - "Hold position", - "Open", - "Closed", - "Safety position" *, - or - "Free position"
Malfunctions detected by the software in the Error2 category (see chapter "Troubleshooting")	Vented
* Safety position = default setting. The actuator is vented in the process.	
These error responses are not a substitute for the required plant-specific precautions and safety facilities.	

13 Commissioning

⚠ WARNING



Possible risk of crushing by the indicator spindle!

- Injury possible, because the actuator must be pressurised in order to reach the flat (only NC drives).
- Do not reach into the operating range of the indicator spindle.

⚠ CAUTION



Hazardous situation!

- Risk of injury or damage
- For correct commissioning, the product must be calibrated to the process valve via the initialization process. Depending on the selected device function (OPEN/CLOSE actuation or positioner) and the specific configuration, this is done automatically the first time the valve moves or needs to be actively started.
- During this commissioning, the valve must be opened and closed by the application of compressed air on the actuator. It must therefore be ensured in advance that this does not lead to a dangerous situation.

NOTICE

Falsified position determination!

- Position determination uses Hall effect sensors and an integrated permanent magnet. External magnetic fields can disrupt and falsify the position determination.
- External magnetic fields, for example, permanent magnets near the device, must be completely avoided (wherever possible) or it must be ensured that they are kept at a maximum possible distance.

1. Use suitable connectors.
2. Connect the control medium lines tension-free and without any bends or knots.
3. Connect the pneumatic tubes and activate the pneumatic control air supply of max. 7 bar (observe the required control pressure for the process valve).
4. Connect the connection cable tension-free and without any bends or knots.
5. Switch on the 24 V DC supply voltage (or 18 to 30 V DC).
6. Connect the communication interface – pin 4: Connect the C/Q cable to a compatible IO-Link master port.

13.1 Initialization

NOTICE

Incorrect initialization!

- Always carry out initialization without operating medium pressure on the process valve. Carry out initialization of the process valve in neutral position (NO/NC).

NOTICE

- For delivery of the product assembled on a valve at the factory, the complete construction is already ready for operation at a control pressure of 5.5 to 6 bar without operating pressure. A reinitialization is recommended if the plant is operated with a different control pressure or if the mechanical end positions have been changed (e.g. seal replacement on the valve or actuator replacement). The initialization is retained even in the event of voltage cutoff.

NOTICE

Initialization depending on the device function

- OPEN/CLOSE actuation: Initialization takes place autonomously (provided that the "Autonomous detection of end positions" mode is active) (see "Autonomous end position process/end position tracking", page 27).
- Positioner: Initialization must be actively started (see "Classic initialization process", page 27).

If initialization has not been carried out beforehand, or if the CLOSED and OPEN end positions have not been detected, the product displays a warning (after a short start-up process) (high-visibility LEDs flash alternately orange/red).

The initialization of the end positions differs depending on the device function with which the device is operated:

OPEN/CLOSE actuation:

Initialization is dependent on the setting of the "Detection of end positions mode" parameter. The "Autonomous" mode is activated as standard, which means that the end positions are determined independently (see "Autonomous end position process/end position tracking", page 27).

Note: The valve can be controlled directly via the process data without having carried out initialization (see "Operation", page 28).

NOTICE**Valve control without initialization**

- The valve can be controlled directly via the process data without having carried out initialization (see "Operation", page 28).

Positioner:

Initialization must be carried out conventionally for normal operation (see "Classic initialization process", page 27).


Note: In order for the valve to be controlled, initialization must first be carried out.

NOTICE**Valve control only with initialization**

- In order for the valve to be controlled, initialization must first be carried out.

In the **autonomous detection of end positions mode** (default setting for OPEN/CLOSE actuation), the end positions are determined independently as soon as the valve moves. The valve is therefore ready for operation directly, reports the end positions back after an initial complete movement cycle (end position A to end position B and back to A) and shows these via the LED display.

In **classic mode** (generally for positioners), the end positions must be calibrated via the active triggering of the initialization process, via an electrical interface (Bluetooth with the corresponding GEMÜ App or ASI-5). If correct initialization has not been carried out, then the device is in a warning state (signalling via the corresponding high-visibility LEDs).

13.1.1 Autonomous end position process/end position tracking

Number 1 in diagram: Without previous end position values, the first two points that are absolutely spaced $\geq 2\%$ apart are calibrated as initialized end positions. Around the initialized OPEN and CLOSED end position values, there is a hysteresis of $\pm 2\%$ in which no action takes place. If the OPEN and/or CLOSED end position value is left at $> 2\%$ (positive or negative), the effect is dependent on the range

Number 2 in diagram: a) Within the switch point range: No message (warning) is sent. If a position in a tolerance band of 2% is approached 5x in succession, the mean value is calculated from this and applied as a new end position. An info message that an end position displacement has occurred is sent.

Number 3 in diagram: b) Outside the switch point range: A warning message ¹⁾ "No movement or incorrect movement" is sent immediately. If a position in a tolerance band of 2% is approached 5x in succession, the mean value is calculated and applied as a new end position. The warning message is acknowledged and an info message that an end position displacement has occurred is sent

¹⁾ Diagnostic messages can also be deactivated via a parameter

* relative to the initialized stroke

The autonomous end position process or end position tracking is an intelligent function, with the help of which the end positions of a valve are independently determined (without external triggering). If this function is active, the end positions are automatically determined the first time the valve moves, and the product is ready for operation immediately. The end positions are continuously monitored and responded to accordingly in case of deviations.

Explanation of the functional principle:

In the autonomous end position tracking mode, a distinction is made between two different conditions, which have an influence on the behaviour of the function.

No initialization: The device observes whether two different end positions have been approached at a certain distance (see diagram). The first two end positions that comply with this condition are calibrated as reinitialized end positions.

Existing initialization: The function determines whether there is a displacement of the end positions over the operating time. If these displacements are outside a certain tolerance range and display a certain consistency (see diagram), the initialized end positions are overwritten by the adjusted initialization values. If this process is triggered, this is indicated by a corresponding message.

A **classic initialization** can also be carried out with autonomous end position tracking activated. This is recommended after a seal replacement or the like, in order to prevent faulty messages regarding end position changes. If the initialization is successful here, then the currently calibrated end positions are overwritten and the tracking operates against these updated end positions. If the actively triggered initialization process is not successful here, then the most recently calibrated initialization positions are deleted.

13.1.2 Classic initialization process**NOTICE**

- The initialization must be repeated every time that the process valve is changed (for example, seal replacement or operator replacement).

NOTICE

- ▶ During initialization, the device checks whether all the necessary conditions are complied with. If all conditions are complied with, the initialization is automatically completed and a confirmation is displayed.
- ▶ If a condition is not complied with, the initialization is aborted with a corresponding error message.

Implementation via IO-Link

Initialization can be started via the process data. Digital device input 3 is set up for this as standard, which can be addressed by process data output bit 2. The operating mode (automatic) is then set automatically.

Process data output bit (Master -> Device) (default setting)*	Logic	Function
2	0	Normal operation
	1	Start initialization

* The function of process data output bit 2 corresponds to the configuration of the parameter: "Digital device input 3 function" -> see 16 Process data

The status of the initialization can be monitored via the process data. Digital device output 3 is set up for this as standard, which can be retrieved by process data output bit 2.

Process data input bit (Device -> Master) (default setting)*	Logic	Function
2	0	Normal operation
	1	Initialization active

* The function of process data output bit 2 corresponds to the configuration of the parameter: "Digital device output 3 function" -> see 15.1 Process data

Procedure:

1. Toggle of process data bit (0 -> 1). This starts the initialization process.
- ⇒ High-visibility LEDs indicate "Initialization active" (flashing white/yellow alternately).
- ⇒ Initialization is carried out automatically and the valve is opened and closed several times.
2. Initialization mode is automatically ended and the automatic operating mode is set.
 3. The valve can be controlled via the corresponding signals depending on the set device function.

13.1.2.1 Implementation via GEMÜ App

The initialization process must be actively started after establishing a connection with the **GEMÜ App** via the **Initialization** quick-action button.

- Call up and start the **Initialization** menu.

⇒ Initialization is carried out automatically and ends automatically. The operating mode (automatic) must then be set for normal operation (the app automatically directs you to this).

13.2 Commissioning the type E1B0 Bluetooth module**NOTICE****Electrostatic discharge!**

- ▶ Damage to the product.
- Ensure that ESD safety precautions are taken.

Please note: The module must be installed and commissioned by an electrician.

1. Make sure that the housing protection of the product is still ensured after installing the type E1B0 Bluetooth module (visually inspecting seals, checking that the type E1B0 Bluetooth module with slider cover is seated correctly, etc.).
2. After installation, the type E1B0 Bluetooth module is automatically supplied with power via the product as soon as it is connected to a power supply.
3. Where there is an existing power supply, the product can be connected to the GEMÜ app.

14 Operation**⚠ WARNING****Hot product!**

- ▶ Danger of burns, as the product heats up at the maximum permissible ambient temperature.
- Wear protective gloves.

NOTICE**Faulty sealing rings or O-rings!**

- ▶ Sudden pressure increase in the product housing due to leakage at the stud bolt sealing ring or pressure sensor O-ring
- Carry out product maintenance regularly and pay attention to the integrity of the sealing rings.

The product is operated by means of an IO-Link master which can be used to influence and monitor the position of the valve. The valve position can be influenced differently depending on the selected device function.

OPEN/CLOSE actuation device function:

The integrated pilot valve can be actuated via a process data output bit (Master -> Device), which pneumatically activates the process valve with compressed air. Digital device input 1 is set up for this as standard, which can be addressed by process data output bit 0.

Process data output bit (Master -> Device) (default setting)*	Logic	Pneumatic actuator	Process valve
0	0	Vented	Process valve in neutral position
	1	Pressurized	Process valve in actuated position

* The function of process data output bit 0 corresponds to the configuration of the parameter: "Digital device input 1 function" -> see 15.1 Process data

Positioner device function:

A set value can be transmitted via the process data outputs (Master -> Device) as a specified signal for the valve position to be controlled, whereby the process valve is pneumatically moved to the specified position using compressed air.

Process data output bits (Master -> Device)	Value [% to 1 decimal place]	Pneumatic actuator	Process valve
8 to 23	0 to 1000	Depending on signal	Process valve target position between 0.0 and 100.0%

In both device functions, the valve end positions can be monitored via a process data input bit (Device -> Master).

End position feedback		
Process data input bit (Device -> Master) (default setting)*	Logic	Process valve
0	0	Process valve not in OPEN position
	1	Process valve in OPEN position
1	0	Process valve not in CLOSED position
	1	Process valve in CLOSED position

* The function of process data output bits 0 and 1 corresponds to the configuration of the parameter: "Digital device output 1 function" or "Digital device output 2 function" -> see 15.1 Process data

In both device functions, the valve end positions can be monitored via a process data input bit (Device -> Master).

Position feedback		
Process data input bits (Device -> Master)	Value [% to 1 decimal place]	Process valve
8 to 23	0 to 1000	Process valve actual position between 0.0 and 100.0%

An app operating option is also available, allowing the process valve to be operated manually in both device functions.

Note: IO-Link operation is possible without restriction, regardless of whether an app connection is available or not. IO-Link output process data (Master -> Slave) for actuation is ignored in "Manual" operating mode. In this case, the process valve can be manually operated using the app.

14.1 Bluetooth interface

Note: Only possible when using the type E1B0 Bluetooth module.

Using an integrated Bluetooth Low Energy interface, the following functions can be used in conjunction with the **GEMÜ app**:

1. Changing the device configuration (parameter settings).
2. Reading out the current device status.
3. Displaying and evaluating historic events.
4. Implementing the initialization.

5. Moving the valve in manual operation.
6. Resetting the device to the default settings.
7. Activating the localization (device detection).
8. Security management (blocking access for a certain group of participants).

NOTICE

- Only one end device can ever be simultaneously connected to the product. For additional participants, this device is not visible during this period.

After starting the app, all compatible GEMÜ products within range are displayed in the connection list. The product that is to be connected can be referenced via the Bluetooth name. In the condition as supplied to the customer, this corresponds to the last four digits of the 12-digit serial number printed on the digital product label (8977 in the following example). The Bluetooth name can optionally be changed at any time after the connection is established (maximum 16 characters).

NOTICE



Safety notice!

- The default state of the Bluetooth interface is activated and it is ready for connection immediately after the product has been electrically commissioned.

NOTICE

Note on Bluetooth!

- The product can be used via the GEMÜ app in its default state as follows:
 - **Bluetooth name** = last four digits of the serial number on the digital name plate.
 - **Bluetooth connection password** = 12-digit serial number or QR code on the digital name plate.
 - It is recommended that both features are changed to any independent information during commissioning in order to increase access protection! Otherwise, anyone with physical access to the product and the digital name plate has access to the above-listed functions!

Digital name plate



In the condition as supplied to the customer, the product is protected against unauthorized access using a unique connection password. The password corresponds to the 12-digit printed serial number or the QR code.

To enter the password, this can optionally be read via the camera scan function on the smartphone/tablet or entered manually. The password can be managed independently and set to any other password (it is recommended that this is done directly after commissioning).

By amending the original password, you lose the option to

read this via the digital name plate. The connection password function can be deactivated, but we do not recommend this. Furthermore, a configuration lock can be set up for the product using a separate optional password, providing the product with additional protection. If this function is activated, you cannot implement any changes to the settings without first entering the password (read-only mode).

There is an option to reset both passwords if you forget these. The user can define whether one, both or none of the passwords are reset via the reset mechanism.

Caution! If you forget your passwords and one or both passwords for the reset mechanism are disabled, the product can only be unlocked by GEMÜ.

Caution! If one or both passwords for the reset mechanism are enabled, anyone with access to the digital name plate (QR code) can remove the password protection.

Reset mechanism:

The following options are available for resetting one of the two passwords (connection or configuration lock password). Both passwords can/must be reset separately from each other.


9. Digital product label (QR code):

⇒ By scanning the QR code that is affixed to the product.

NOTICE

- A setting parameter can be used to block the reset of one or both passwords.

14.2 Basic operation of the app



The GEMÜ app comprises multiple function modules that can be accessed via the bottom navigation at the bottom edge of the display. The functions for operating the product can be found in the "Connect" area. All available GEMÜ products within range are displayed in the connection list. The connection is established by tapping a selected product (usually the connection password must also be entered). The figure above provides a rough overview of the construction after a connection with a product has been established. You can navigate within the "Connect" area by selecting the "Overview", "Settings" or "Status" tabs. Important info, error or warning mes-

sages can be accessed on all pages via the bell icon. On the overview page, the initialization of the product can be started and executed, among other functions. The menu can be opened via the gear icon. Here, you can change the password settings, reset the product to default settings or update the firmware.


14.3 Sensor system for status monitoring

Various sensors are installed on the device which make it possible to diagnose the status. The measured values are output on the electrical interface(s) and so can be processed. Additionally, for each relevant measured value, warning thresholds are defined that generate a warning or error message when they are not reached or are exceeded. This means that unacceptable influences that would damage the device or reduce its service life can be reacted to in a timely manner.

The following measured values are detected internally:

- Internal temperature
- Internal humidity
- Internal pressure
- Control air supply pressure
- Installation position (in two directions)
- Acceleration (in three axes)
- Current consumption
- Supply voltage

The axes for evaluating the acceleration in the X, Y and Z directions are defined in accordance with the visualisation below.



The following correlation is provided in the details of the mounting angles:

- The frontal inclination angle corresponds to the Z axis.
- The side inclination angle corresponds to the X axis.

14.4 Integrated diagnostic functions

14.4.1 Integrated diagnostic functions (OPEN/CLOSE actuation device function)

In the OPEN/CLOSE actuation device function, GEMÜ 44A0 has integrated diagnostic functions that provide information early on about irregularities in the switch characteristics of pneumatically operated process valves. These diagnostic functions continuously monitor the movements of the actuator and detect deviations from normal operating behaviour.

Operating principle:

During operation, the travel times for each switching movement (Open/Closed) are continuously measured and evaluated. If there is a valid initialization and an activated diagnostic notification (parameter: "Diagnostic messages"), the system automatically detects deviations from typical movement profiles.

This can generate the following messages:

- **"No movement or incorrect movement in the Open/Closed direction":**
Indicates that no or incomplete movement has taken place (e.g. due to no or insufficient control pressure or mechanical blockage). It was detected that an actuation signal for an end position movement was issued, but the expected end position was not reached after the alarm time had elapsed and the position did not change plausibly in this direction.
- **"Duration error in the Open/Closed direction":**
Indicates an above-average switching time, e.g. in the event of a pressure drop or mechanical resistance. It was detected that an actuation signal for an end position movement was issued, but the expected end position was not reached within the alarm time. However, the position continued to change in the direction of the expected end position.
- **"Undefined change in position in the Open/Closed direction":**
Indicates unexpected movements without valid actuation (e.g. for leakages or uncontrolled pressure changes). It was detected that the position changes in the opposite direction to the actuation signal.

The alarm time for the error detection is calculated dynamically using the determined travel time (formula: Current travel time x 2 + 1000 ms). This allows a reliable distinction to be made between normal and faulty conditions. The travel times are continuously recorded during operation. If these are within a comparable percentage range for the same direction (open or closed), the current open and closed travel times are determined or updated from this sequence of travel time measurements.

The end position always refers to the switch point range of the respective end position. The switch points can be changed or set via the parameter: "Switch point Open/Closed".

Active warning messages are automatically acknowledged as soon as the movements are carried out without fault again or the "Diagnostic messages" parameter is deactivated.

14.4.2 Integrated diagnostic functions (positioner device function)

In the positioner device function, GEMÜ 44A0 has integrated diagnostic functions that provide information early on about irregularities in the control characteristics of pneumatically operated process valves. These diagnostic functions continuously monitor the movements of the actuator and detect deviations from normal operating behaviour.

Operating principle:

The movement profile of the valve is determined during initialization. If there is a valid initialization and an activated diagnostic notification (parameter: "Diagnostic messages"), the system automatically detects deviations from the expected movement profile.

This can generate the following messages:

- "No movement or incorrect movement":

Indicates that no or incomplete movement has taken place or the valve position does not correspond to the specified target variable (e.g. due to no or insufficient control pressure or mechanical blockage). It was detected that the valve position specified by the target variable cannot be adjusted.

Active warning messages are automatically acknowledged as soon as the movements are carried out without fault again, the "Diagnostic messages" parameter is deactivated, the device is restarted, the initialization is deleted (perform factory reset) or a new initialization is started.

If these diagnostic messages are generated incorrectly or by known, unchangeable external influences, they can be deactivated via the "Diagnostic messages" parameter using IO-Link or the app. However, it is recommended to perform a new initialization first if the previous one was some time ago or a number of operating hours ago.

15 Specific data relating to IO-Link

Physics:	Physics 2 (3-wire design)
Port configuration:	Type A port
Transmission rate:	38400 baud
Min. cycle time:	10 ms
Vendor ID:	401
Device ID:	4497409 (0x44A001)
ISDU support:	Yes
SIO operation:	No
IO-Link specification:	V1.1.4
Block parameterization:	Yes
Data storage:	Yes

Information for IO-Link: IODD files can be downloaded via <https://ioddfinder.io-link.com/> or www.gemugroup.com.

16 Process data

Outputs (master → device)			
Bit	Description	Default setting function	Logic
0	Digital device input 1	"OPEN/CLOSE actuation" device function: Pilot valve actuation "Positioner" device function: Deactivated	"OPEN/CLOSE actuation" device function: 0 = Integrated pilot valve not actuated 1 = Integrated pilot valve actuated
1	Digital device input 2	Deactivated	
2	Digital device input 3	Initialization input	0 = normal operation 1 = activate initialization
3	Digital device input 4	Localization input	0 = location function inactive 1 = activate location function
4	Digital device input 5	Deactivated	
5	Digital device input 6	Deactivated	
6	Digital device input 7	Deactivated	
7	Digital device input 8	Deactivated	
8 to 23	Set value input	"OPEN/CLOSE actuation" device function: Deactivated "Positioner" device function: Specification of target valve position	0.0 to 100.0% Process valve position

Device-side digital input signals can be used to start various actions, such as starting initialization/location function The function can be set by the associated non-cyclical parameter data			
Digital device input 1 to 8 function	0	Deactivated	No function
	1 ¹⁾	Actuation of pilot valve	The integrated pilot valve is actuated if this signal is active.
	3	Initialization input	Initialization is activated if this signal is active.
	4	Localization input	The location function is activated if this signal is active.
	5	On/off error position	If there is no active signal, the valve is moved to the defined position via the "Error position" parameter. If this signal is active, operation is performed in accordance with the set operating mode.
	6 ²⁾	Break/Normal control	If there is no active signal, the automatic control system is paused and the valve is therefore kept in the current position. If this signal is active, control is performed in accordance with the set value signal and set operating mode.
	7 ²⁾	Open until OPEN travel stop	If there is an active signal, the process valve is moved to the mechanical OPEN end position (thereby also leaving a set operating range)
	8 ²⁾	Open until CLOSED travel stop	If there is an active signal, the process valve is moved to the mechanical CLOSED end position (thereby also leaving a set operating range)
¹⁾ Only "OPEN/CLOSE actuation" device function			
²⁾ Only "Positioner" device function			

Inputs (device → master)			
Bit	Description	Default setting function	Logic
0	Digital device output 1	OPEN feedback	0 = process valve not in OPEN position 1 = process valve in OPEN position
1	Digital device output 2	CLOSED feedback	0 = process valve not in CLOSED position 1 = process valve in CLOSED position
2	Digital device output 3	Feedback for initialization active	0 = normal operation 1 = initialization mode active
3	Digital device output 4	Deactivated	
4	Digital device output 5	Deactivated	
5	Digital device output 6	Deactivated	
6	Digital device output 7	Deactivated	
7	Digital device output 8	Deactivated	
8 to 23	Analogue device output	Valve position feedback	0.0 to 100.0% process valve position

Device-side digital output signals can be used to output various statuses, for example end position feedback/errors/alarms. → The function can be set via the associated non-cyclical parameter data			
Digital device output 1 to 8 function	0	Deactivated	No function
	1	OPEN feedback	Feedback for valve position OPEN
	2	CLOSED feedback	Feedback for valve position CLOSED
	3	Error output	Output if an error is detected
	4	Warning output	Output if a warning is detected
	5	Feedback for initialization active	Feedback when initialization is active
	6 ¹⁾	Feedback for "Off" operating mode	Feedback when the product is in operating mode "Off" (see "Operating mode" parameter)
¹⁾ Only "Positioner" device function			

17 IO-Link system commands

System commands can be transmitted via the subindex 0x0002. The following are supported by the device:

Designation	System command	GEMÜ App parameter number	Description
Application Reset	0x81		Resets the technology-specific parameters. This allows the device to be brought into a pre-defined state without interrupting the corresponding communication and without the need for a switch-off cycle.
Back-to-Box	0x83		This function allows the device to be reset to the original parameterization. This command is useful if, for example, a device is removed from an existing plant and reactivated as a spare part. After the command has been executed, IO-Link communication is stopped until the next device start.
Reset Cycle Counter User	0xA2	S21	Resets the user switching cycle counter.
Reset Valve Actuation Counter User	0xA3	S01	Resets the user valve actuation counter.

18 Parameter list (IO-Link and GEMÜ app)

NOTICE																
► All IO-Link parameters that contain sub-indexes can also be addressed in bundles via sub-index 0.																
IO-Link parameter								GEMÜ app parameter number	GEMÜ app access	Parameter name	Parameter de- scription	Default setting	Selection values	Description	IO-Link menu	GEMÜ app menu
Index	Su- bindex	Bit	Access rights	Length	Data type	Data stor- age	Back-to- Box									
HEX	DEZ															
0x0010	0	0–...	RO	5 bytes	StringT	Yes	No	-	-	Vendor Name			“GEMUE”	Manufacturer	Identification	-
0x0012	0	0–...	RO	12 bytes	StringT	Yes	No	-	-	Product Name			“44A0 IO-Link”	Manufacturer specific device name	Identification	-
0x0013	0		RO	4 bytes	StringT	Yes	No	-	-	Product ID			“44A0”	Equipment cat- egory	Identification	-
0x0014			RO	18 bytes	StringT	Yes	No	-	-	Product text			Multi-functional combi switchbox and size re- cognised by the soft- ware (1, 2 or 3)	Product text	Identification	-
0x0015	0	0–...	RO	variable	StringT	Yes	No	S11	RO	Serial number			“RRRRRRRR/IIII” (traceability number and index)	Serial number of the device	Identification	Device status Other values
0x0016	0	0–...	RO	52 bytes	StringT	Yes	No	S03	RO	Hardware Revi- sion			“xxxx/xx yyyy/yy zzzz/ zz” depending on the quantity of circuit boards Spaces are added in front of the contents	0x0016	0	Device status Other values
0x0017	0	0–...	RO	21 bytes	StringT	Yes	No	S04	RO	Firmware Revi- sion			“Vx.x.x.x” Spaces are added in front of the contents	0x0017	0	Device status Other values
0x0018	0	0–...	RW	32 bytes	StringT	Yes	Yes	-	-	Application- specific tag		***	“*** ”	Option to define a designation specific to the application	Identification/ tags	-
0x0019	0	0–...	RW	32 bytes	StringT	Yes	Yes	-	-	Function Tag		***	“*** ”	Option to define a functional des- ignation	Identification/ tags	-
0x001A	0	0–...	RW	32 bytes	StringT	Yes	Yes	-	-	Location Tag		***	“*** ”	Option to define a location-spe- cific designation	Identification/ tags	-
0x0024			RO	1 byte	UIntegerT	-	-	-	-	Device Status				Contains the current status of the device	Diagnostics Device status	-
0x0025			RO	variable	ArrayT	-	-	-	-	Detailed Device Status				Detailed list of events for evalu- ating the device status	Diagnostics Device status	-
0x0028			RO	3 bytes	UIntegerT	-	-	-	-	Process Data (Device -> Mas- ter)				Process data outputs (display of process data via ISDU)	-	-

IO-Link parameter								GEMÜ app parameter number	GEMÜ app access	Parameter name	Parameter de- scription	Default setting	Selection values		Description	IO-Link menu	GEMÜ app menu
Index	Su- bindex	Bit	Access rights	Length	Data type	Data stor- age	Back-to- Box										
HEX	DEZ																
0x0029			RO	1 byte	UIntegerT	-	-	-	-	Process Data (Master -> Device)					Process data in- puts (display of process data via ISDU)	-	-
0x0041	0		RW	2 bytes	RecordT	Yes				Device configur- ation						Parameters Ba- sic settings Device configur- ation	Settings Device configuration
	1	0–3	RW	4 bits	uint:4	Yes	Yes	M03	RW	Device function ²⁾	Defines the device function in which the device should be operated	0 (OPEN/CLOSE actuation)	0	OPEN/CLOSE actuation	The valve is moved to the CLOSED or OPEN end posi- tion depending on the active signal		
													1	Extended OPEN/ CLOSE actuation	Currently identical to OPEN/CLOSE actuation		
													2	Positioner ³⁾	The valve posi- tion specified by the set value signal is ap- proached		
	2	8–11	RW	4 bits	uint:4	Yes	Yes	M01	RW	Operating mode	Defines the op- erating mode	1 (Automatic)	0	Off ¹⁾	No response to signal change		
													1	Automatic	Control via ex- ternal signal		
													2	Manual	Manual control possible		
0x0042	0		RW	1 byte	RecordT	Yes				Digital device output 1					Digital output 1 configuration	Parameters In- puts/outputs Digital outputs	Settings In- puts/outputs
	1	0–7	RW	8 bits	uint:8	Yes	Yes	P78	R/W	Digital device output 1 func- tion	Defines the function of device-side di- gital output 1	1 (OPEN feed- back)	0	Deactivated	No function		
													1	OPEN feedback	Feedback for valve position OPEN		
													2	CLOSED feed- back	Feedback for valve position CLOSED		
													3	Error output	Output if an er- ror is detected		
													4	Warning output	Output if a warn- ing is detected		
													5	Feedback for ini- tialization active	Feedback when initialization is active		
													6	Feedback for “Off” operating mode ¹⁾	Feedback when the product is in operating mode “Off” (see “Oper- ating mode” parameter)		

IO-Link parameter								GEMÜ app parameter number	GEMÜ app access	Parameter name	Parameter de- scription	Default setting	Selection values		Description	IO-Link menu	GEMÜ app menu
Index	Su- bindex	Bit	Access rights	Length	Data type	Data stor- age	Back-to- Box										
HEX	DEZ																
0x0043	0		RW	1 byte	RecordT	Yes				Digital device output 2					Digital output 2 configuration	Parameters In- puts/outputs Digital outputs	Settings In- puts/outputs
	1	0–7	RW	8 bits	uint:8	Yes	Yes	P79	R/W	Digital device output 2 func- tion	Defines the function of device-side di- gital output 2	2 (CLOSED feed- back)	See digital device output 1 for se- lection values	Digital output 1 for se- lection values			
0x0044	0		RW	1 byte	RecordT	Yes				Digital device output 3					Digital output 3 configuration	Parameters In- puts/outputs Digital outputs	Settings In- puts/outputs
	1	0–7	RW	8 bits	uint:8	Yes	Yes	P80	R/W	Digital device output 3 func- tion	Defines the function of device-side di- gital output 3	5 (Operating mode feedback)		See digital device output 1 for se- lection values			
0x0045	0		RW	1 byte	RecordT	Yes				Digital device output 4					Digital output 4 configuration	Parameters In- puts/outputs Digital outputs	Settings In- puts/outputs
	1	0–7	RW	8 bits	uint:8	Yes	Yes	P81	R/W	Digital device output 4 func- tion	Defines the function of device-side di- gital output 4	0 (Deactivated)		See digital device output 1 for se- lection values			
0x0046	0		RW	1 byte	RecordT	Yes				Digital device output 5					Digital output 5 configuration	Parameters In- puts/outputs Digital outputs	Settings In- puts/outputs
	1	0–7	RW	8 bits	uint:8	Yes	Yes	P82	R/W	Digital device output 5 func- tion	Defines the function of device-side di- gital output 5	0 (Deactivated)		See digital device output 1 for se- lection values			
0x0047	0		RW	1 byte	RecordT	Yes				Digital device output 6					Digital output 6 configuration	Parameters In- puts/outputs Digital outputs	Settings In- puts/outputs
	1	0–7	RW	8 bits	uint:8	Yes	Yes	P83	R/W	Digital device output 6 func- tion	Defines the function of device-side di- gital output 6	0 (Deactivated)	See digital device output 1 for se- lection values				
0x0048	0		RW	1 byte	RecordT	Yes				Digital device output 7				Digital output 7 configuration	Parameters In- puts/outputs Digital outputs	Settings In- puts/outputs	
	1	0–7	RW	8 bits	uint:8	Yes	Yes	P84	R/W	Digital device output 7 func- tion	Defines the function of device-side di- gital output 7	0 (Deactivated)	See digital device output 1 for se- lection values				
0x0049	0		RW	1 byte	RecordT	Yes				Digital device output 8				Digital output 8 configuration	Parameters In- puts/outputs Digital outputs	Settings In- puts/outputs	
	1	0–7	RW	8 bits	uint:8	Yes	Yes	P85	R/W	Digital device output 8 func- tion	Defines the function of device-side di- gital output 8	0 (Deactivated)	See digital device output 1 for se- lection values				
0x004F	0		RW	3 bytes	RecordT	Yes				Error configura- tion						Parameters Er- ror functions	Settings Error functions
	1	0–15	RW	16 bits	uint:16	Yes	Yes	P37	R/W	Error time	Defines the de- bounce time in the event of er- ror detection	0.1 s	1 to 1000 (0.1 to 100.0 s)	Defines the de- bounce time in the event of er- ror detection			

IO-Link parameter								GEMÜ app parameter number	GEMÜ app access	Parameter name	Parameter de- scription	Default setting	Selection values		Description	IO-Link menu	GEMÜ app menu
Index	Su- bindex	Bit	Access rights	Length	Data type	Data stor- age	Back-to- Box										
HEX	DEZ																
	2	16–18	RW	3 bits	uint:3	Yes	Yes	P36	R/W	Error position	Defines the valve position in the event of er- ror detection	3 (Safety position)	0	Hold position	Valve remains in its current posi- tion		
													1	Open	The valve is moved to the OPEN position		
													2	Closed	The valve is moved to the CLOSED posi- tion		
													3	Safety position	Valve is vented		
													4	Free position	An optional valve position to be approached can be stipu- lated with para- meter “Free er- ror position”. Af- fects the “OPEN/CLOSE actuation” device function in the same way as the “Safety position” set- ting.		
													3	19	RW		
												1	Activated	Diagnostic mes- sages active			
	8	24–39	RW	16 bits	uint:16	Yes	Yes	P52	R/W	Free error posi- tion	Defines the valve position to be approached if an error is detec- ted	0.0%	0 to 1000 (0.0 to 100.0%)		Defines the valve position to be approached if an error is detec- ted	Parameters Ba- sic settings	Settings Dis- play settings
0x0050	0		RW	2 bytes	RecordT	Yes				Basic settings							
	1	0	RW	1 bit	Boolean	Yes	Yes	P56	R/W	Inversion of LED colours	Activates/deac- tivates the inver- sion of LED col- ours for the end position display	0 (Deactivated)	0	Deactivated	OPEN position (green), CLOSED position (or- ange), moving towards OPEN (flashing green), moving towards CLOSED (flash- ing orange)		

IO-Link parameter								GEMÜ app parameter number	GEMÜ app access	Parameter name	Parameter de- scription	Default setting	Selection values		Description	IO-Link menu	GEMÜ app menu
Index	Su- bindex	Bit	Access rights	Length	Data type	Data stor- age	Back-to- Box										
HEX	DEZ																
													1	Activated	OPEN position (orange), CLOSED posi- tion (green), moving towards OPEN (flashing orange), moving towards CLOSED (flash- ing green)		Settings Initial- ization settings
	2	1	RW	1 bit	Boolean	Yes	Yes	P43	R/W	Inversion of the travel sensor signal	Activates/deac- tivates inversion of the travel sensor signal	0 (Deactivated)	0	Deactivated	Standard direc- tion of the travel sensor signal		
													1	Activated	Inversed direc- tion of the travel sensor signal		
	3	2	RW	1 bit	Boolean	Yes	Yes	P51	R/W	Detection of end positions mode ⁴⁾	Defines the de- tection of end positions mode	1 (Autonomous)	0	Classic	Detection of end positions via ini- tialization		Settings Initial- ization settings
													1	Autonomous	Intelligent detec- tion of end posi- tions with autonomous tracking (recom- mended)		
	6	5	RW	1 bit	Boolean	Yes	No	-	-	Bluetooth inter- face	Activates/deac- tivates the Bluetooth inter- face	1 (Activated)	0	Deactivated	Bluetooth inter- face inactive		-
													1	Activated	Bluetooth inter- face active		
	9	8–10	RW	3 bits	uint:3	Yes	Yes	P55	R/W	High visibility position indic- ator	Activates/deac- tivates the visual end position dis- play	1 (Activated)	0	Deactivated	High visibility LED for position feedback inact- ive	Settings Dis- play settings	
													1	Activated	High visibility LED for position feedback active		
													2	Dimmed	High visibility LED for position feedback dimmed		
0x0051	0		RW	4 bytes	RecordT	Yes				End position feedback					Configuring the switch points	Parameters Ba- sic settings Switch points	Settings In- puts/outputs
	1	0–15	RW	16 bits	uint:16	Yes	Yes	P53	R/W	Switch point OPEN	Defines switch point OPEN	75%	10.0 to 100.0%		The value must be at least 10.0% larger than the set value for switch point CLOSED		

IO-Link parameter								GEMÜ app parameter number	GEMÜ app access	Parameter name	Parameter de- scription	Default setting	Selection values		Description	IO-Link menu	GEMÜ app menu
Index	Sub-index	Bit	Access rights	Length	Data type	Data stor- age	Back-to- Box										
HEX	DEZ																
	2	16–31	RW	16 bits	uint:16	Yes	Yes	P54	R/W	Switch point CLOSED	Defines switch point CLOSED	12%	0.0 to 90.0%		The value must be at least 10.0% smaller than the set value for switch point OPEN		
0x0053	0		RO	4 bytes	RecordT	No				Initialized end positions						Observation Valve informa- tion	Device status Other values
	1	0–15	RO	16 bits	uint:16	No	Yes	S05	RO	Absolute travel sensor position OPEN	Displays the valve absolute position for the OPEN end posi- tion	0	0 to 1000 (0.0 to 100.0%)				
	2	16–31	RO	16 bits	uint:16	No	Yes			Absolute travel sensor position CLOSED	Displays the valve absolute position for the CLOSED end po- sition	0	0 to 1000 (0.0 to 100.0%)				
0x0054	0		RO	2 bytes	RecordT	No				Absolute valve position						Observation Valve informa- tion	Device status Other values
	1	0–15	RO	16 bits	uint:16	No	No	S60	RO	Current abso- lute position	Displays the ab- solute position of the travel sensor	0	0 to 1000 (0.0 to 100.0%)		Current valve position in % rel- ative to the total stroke		
0x0056	0		RW	30 bytes	RecordT	No				Counter					Switching cycle counter	Counter read- ings: Observation Counter read- ings Warning thresholds: Parameters Counter reading alarm threshold	Device status Other values
	1	0–31	RO	32 bits	uint:32	No	No	S21	R/W	User switching cycle counter	Displays the number of user switching cycles counted	0	0 to 2,147,483,647		Counter reading can be reset (via IO-Link system command or app)		
	2	32–63	RO	32 bits	uint:32	No	No	S23	RO	Total switching cycle counter	Displays the total number of switching cycles counted	0	0 to 2,147,483,647		The counter reading cannot be reset. To do so, instead use parameter “Valve actu- ations user counter”		
	3	64–95	RW	32 bits	uint:32	Yes	No	S22	R/W	Warning threshold for user switching cycles	Defines the warning threshold for user switching cycles	5,000,000	1 to 2,147,483,647		This parameter relates to the parameter “User switching cycle counter”.		
	4	96–127	RO	32 bits	uint:32	No	No	S01	RO	Valve actu- ations user counter	Displays the number of user valve actuations counted	0	0 to 2,147,483,647		Counter reading can be reset (via IO-Link system command or app)		

IO-Link parameter								GEMÜ app parameter number	GEMÜ app access	Parameter name	Parameter de- scription	Default setting	Selection values	Description	IO-Link menu	GEMÜ app menu
Index	Su- bindex	Bit	Access rights	Length	Data type	Data stor- age	Back-to- Box									
HEX	DEZ															
	5	128–159	RO	32 bits	uint:32	No	No	S13	RO	Valve actu- ations total counter	Displays the total number of valve actuations counted	0	0 to 2,147,483,647	The counter reading cannot be reset. To do so, instead use parameter “Valve actu- ations user counter”		
	6	160–191	RW	32 bits	uint:32	Yes	No	S02	R/W	Warning threshold for valve actuations user counter	Defines the warning threshold for the user counter for valve actuations	5,000,000	1 to 2,147,483,647	This parameter relates to the parameter “Valve actu- ations user counter”.		
	7	192–207	RO	16 bits	uint:16	No	No	S61	RO	Valve actu- ations warning ratio	Displays the rel- ative degree of wear on the pilot valve module	0.0%	0 to 1000 (0.0 to 100.0%)	This parameter shows only the percentage ratio of the counted valve actuations in relation to the defined warning threshold, and can thus display a relative degree of wear. The warning threshold must be set based on empirical values or other spe- cifications, so as to be able to read off a sens- ible degree of wear.		
	8	208–239	RO	32 bits	uint:32	No	No	S20	RO	Device starts counter	Displays the number of product starts	0	0 to 2,147,483,647			
0x005A	0		RO	8 bytes	RecordT	No				Operating hours				Operating hours counter	Observation Operating hours	Device status Operating hours
	1	0–31	RO	32 bits	uint:32	No	No	S70	RO	Total operating hours	Displays the total operating hours	0	0–2,147,483,647 s			
	2	32–63	RO	32 bits	uint:32	No	No	S71	RO	Operating hours since last start	Displays operat- ing hours at/ since the last start	0	0–2,147,483,647 s			
0x005B	0		RO	40 bytes	RecordT	No				Maintenance in- dicator				Maintenance in- formation	Diagnostics Maintenance in- dicator	Maintenance

IO-Link parameter								GEMÜ app parameter number	GEMÜ app access	Parameter name	Parameter de- scription	Default setting	Selection values		Description	IO-Link menu	GEMÜ app menu
Index	Su- bindex	Bit	Access rights	Length	Data type	Data stor- age	Back-to- Box										
HEX	DEZ																
	1	0–63	RO	64 bits	TimeT	No	No	S73	R/W	User time stamp maintenance	Defines the time stamp for when maintenance was carried out	2025-01-01 00:00:00.000	YYYY-MM-DD HH:MM:SS.SSS		The entry must be actively made by the user. This means that the time of the most recently per- formed mainten- ance can be stored.		
	2	64–319	RO	256 bits	StringT	No	No	S74	R/W	User mainten- ance informa- tion	Defines addi- tional informa- tion about the maintenance performed	***	UTF-8		The entry must be actively made by the user. This means that addi- tional informa- tion about the most recently performed main- tenance can be stored (e.g. what specifically was maintained and by whom).		
0x005C	0		RO	1 byte	RecordT	No			RO	Valve informa- tion					Observation Valve informa- tion	Settings Initial- ization settings	
	1	0–3	RO	4 bits	uint:4	No	Yes	S19	RO	Control function	Displays the de- termined control function of the valve	0	0 undefined				No control func- tion recognised
													1 NC				Normally closed (NC) control function detec- ted
													2 NO				Normally open (NO) control function detec- ted
0x0062	0		RO	4 bytes	RecordT	No				Operating times				Operating times	Observation Valve informa- tion	Device status Other values	
	1	0–15	RO	16 bits	uint:16	No	Yes	S09	RO	Operating time OPEN	Displays the dur- ation of opening the valve	0	0 to 999 (0.0 to 99.9 s)				
	2	16–31	RO	16 bits	uint:16	No	Yes	S10	RO	Operating time CLOSED	Displays the dur- ation of closing the valve	0	0 to 999 (0.0 to 99.9 s)				
0x0064	0		RW	1 byte	RecordT	Yes				Digital device in- put 1					Digital input 1 configuration	Parameters In- puts/outputs Digital inputs	Settings In- puts/outputs
	1	0–7	RW	8 bits	uint:8	Yes	Yes	P70	R/W	Digital device input 1 function	Defines the function of device-side di- gital input 1	Combi switch- box device func- tion: 1 (actuation of pi- lot valve)	0	Deactivated	No function		
													1	Actuation of pi- lot valve	The pilot valve is actuated if this signal is active.		

IO-Link parameter								GEMÜ app parameter number	GEMÜ app access	Parameter name	Parameter de- scription	Default setting	Selection values		Description	IO-Link menu	GEMÜ app menu
Index	Su- bindex	Bit	Access rights	Length	Data type	Data stor- age	Back-to- Box										
HEX	DEZ																
												Positioner device function: 0 (deactivated)	3	Initialization in- put	Initialization is activated if this signal is active		
													4	Localization in- put	The location function is activ- ated if this sig- nal is active		
													5	On/off error pos- ition	If there is no act- ive signal, the valve is moved to the defined position via the “Error position” parameter. If this signal is active, operation is performed in accordance with the set operat- ing mode.		
													6	Break/Normal control ¹⁾	If there is no act- ive signal, the automatic con- trol system is paused and the valve is there- fore kept in the current position. If this signal is active, control is performed in ac- cordance with the set value signal and set operating mode.		
													7	Open until OPEN travel stop ¹⁾	If there is an act- ive signal, the process valve is moved to the mechanical OPEN end posi- tion (thereby also leaving a set operating range)		

IO-Link parameter								GEMÜ app parameter number	GEMÜ app access	Parameter name	Parameter de- scription	Default setting	Selection values		Description	IO-Link menu	GEMÜ app menu
Index	Sub-index	Bit	Access rights	Length	Data type	Data stor- age	Back-to- Box										
HEX	DEZ																
													8	Close until CLOSED travel stop ¹⁾	If there is an act- ive signal, the process valve is moved to the mechanical CLOSED end po- sition (thereby also leaving a set operating range)		
0x0065	0		RW	1 byte	RecordT	Yes				Digital device in- put 2					Digital input 2 configuration	Parameters In- puts/outputs Digital inputs	Settings In- puts/outputs
	1	0–7	RW	8 bits	uint:8	Yes	Yes	P70	R/W	Digital device input 2 function	Defines the function of device-side di- gital input 2	0 (deactivated)		See digital device input 1 for selec- tion values			
0x0066	0		RW	1 byte	RecordT	Yes				Digital device in- put 3					Digital input 3 configuration	Parameters In- puts/outputs Digital inputs	Settings In- puts/outputs
	1	0–7	RW	8 bits	uint:8	Yes	Yes	P70	R/W	Digital device input 3 function	Defines the function of device-side di- gital input 3	3 (initialization input)		See digital device input 1 for selec- tion values			
0x0067	0		RW	1 byte	RecordT	Yes				Digital device in- put 4					Digital input 4 configuration	Parameters In- puts/outputs Digital inputs	Settings In- puts/outputs
	1	0–7	RW	8 bits	uint:8	Yes	Yes	P70	R/W	Digital device input 4 function	Defines the function of device-side di- gital input 4	4 (localization input)		See digital device input 1 for selec- tion values			
0x0068	0		RW	1 byte	RecordT	Yes				Digital device in- put 5					Digital input 5 configuration	Parameters In- puts/outputs Digital inputs	Settings In- puts/outputs
	1	0–7	RW	8 bits	uint:8	Yes	Yes	P70	R/W	Digital device input 5 function	Defines the function of device-side di- gital input 5	0 (deactivated)		See digital device input 1 for selec- tion values			
0x0069	0		RW	1 byte	RecordT	Yes				Digital device in- put 6					Digital input 6 configuration	Parameters In- puts/outputs Digital inputs	Settings In- puts/outputs
	1	0–7	RW	8 bits	uint:8	Yes	Yes	P70	R/W	Digital device input 6 function	Defines the function of device-side di- gital input 6	0 (deactivated)		See digital device input 1 for selec- tion values			
0x006A	0		RW	1 byte	RecordT	Yes				Digital device in- put 7					Digital input 7 configuration	Parameters In- puts/outputs Digital inputs	Settings In- puts/outputs
	1	0–7	RW	8 bits	uint:8	Yes	Yes	P70	R/W	Digital device input 7 function	Defines the function of device-side di- gital input 7	0 (deactivated)		See digital device input 1 for selec- tion values			
0x006B	0		RW	1 byte	RecordT	Yes				Digital device in- put 8					Digital input 8 configuration	Parameters In- puts/outputs Digital inputs	Settings In- puts/outputs

IO-Link parameter								GEMÜ app parameter number	GEMÜ app access	Parameter name	Parameter de- scription	Default setting	Selection values		Description	IO-Link menu	GEMÜ app menu
Index	Su- bindex	Bit	Access rights	Length	Data type	Data stor- age	Back-to- Box										
HEX	DEZ																
	1	0–7	RW	8 bits	uint:8	Yes	Yes	P70	R/W	Digital device input 8 function	Defines the function of device-side di- gital input 8	0 (deactivated)		See digital device input 1 for selec- tion values			
0x006E	0		RW	1 byte	RecordT	Yes			R/W	Preferred direc- tion ¹⁾					Parameters Er- ror functions	Settings Error functions	
	1	0–2	RW	3 bits	uint:3	Yes	Yes	P97	R/W	Preferred direc- tion	Defines the pre- ferred direction which will be ap- proached in case of implaus- ible signals	3 (error position)	0	Hold position			While implaus- ible signals are active, the valve remains in the current position
													1	Open			While implaus- ible signals are active, the valve is moved to the OPEN position
													2	Closed			While implaus- ible signals are active, the valve is moved to the CLOSED posi- tion
													3	Error position			The action spe- cified in the “Er- ror position” parameter is performed (as long as implaus- ible signals are present)
0x0078	0		RO	26 bytes	RecordT	No				Status sensor system				Environment and status sensor system	Diagnostics Status sensor system	Device status Sensor system	
	1	0–15	RO	16 bits	int:16	No	No	S40	RO	Internal temper- ature	Indicates the measured in- ternal temperat- ure	0	-400 to 1000 (-40.0 °C to 100.0 °C)				
	2	16–31	RO	16 bits	uint:16	No	No	S41	RO	Internal pres- sure	Indicates the measured in- ternal pressure	0	260 to 1260 (260 mbar to 1260 mbar)				
	3	32–47	RO	16 bits	int:16	No	No	S47	RO	Laterally in- clined installa- tion position	Laterally in- clined installa- tion position	0	-180 to 180 (-180° to 180°)				
	4	48–63	RO	16 bits	int:16	No	No	S46	RO	Frontally in- clined installa- tion position	Frontally in- clined installa- tion position	0	-180 to 180 (-180° to 180°)				
	5	64–79	RO	16 bits	int:16	No	No	S48	RO	Acceleration in X axis	Acceleration in X axis	0	-15696 to 15696 (-156.96 m/s² to 156.96 m/s²)				

IO-Link parameter								GEMÜ app parameter number	GEMÜ app access	Parameter name	Parameter de- scription	Default setting	Selection values	Description	IO-Link menu	GEMÜ app menu
Index	Sub-index	Bit	Access rights	Length	Data type	Data stor- age	Back-to- Box									
HEX	DEZ															
	6	80–95	RO	16 bits	int:16	No	No	S49	RO	Acceleration in Y axis	Acceleration in Y axis	0	-15696 to 15696 (-156.96 m/s² to 156.96 m/s²)			
	7	96–111	RO	16 bits	int:16	No	No	S50	RO	Acceleration in Z axis	Acceleration in Z axis	0	-15696 to 15696 (-156.96 m/s² to 156.96 m/s²)			
	8	112–127	RO	16 bits	uint:16	No	No	S44	RO	Supply voltage	Indicates the measured supply voltage	0	0 to 3600 (0.00 V to 36.00 V)			
	9	128–143	RO	16 bits	uint:16	No	No	S45	RO	Current consumption	Indicates the measured current consumption	0	0 to 375 (0 mA to 375 mA)			
	10	144–159	RO	16 bits	uint:16	No	No	S43	RO	Internal humidity	Indicates the measured relative internal humidity	0	0 to 1000 (0.0% to 100.0%)			
	11	160–175	RO	16 bits	uint:16	No	No	S42	RO	Control air supply pressure	Indicates the measured supply pressure of the control air	0	0 to 300 (0.0 bar to 30.0 bar)			
	12	176–191	RO	16 bits	uint:16	No	No	S51	RO	Actuator chamber pressure	Indicates the measured chamber pressure of the connected actuator	0	0 to 300 (0.0 bar to 30.0 bar)			
0x007A	0		RW	16 bytes	RecordT					Sensor value warning threshold				Sensor value alarm threshold	Parameters Sensor value alarm threshold	Settings Diagnostics settings
	1	0–15	RW	16 bits	int:16	Yes	Yes	P89	R/W	Alarm threshold for min. internal temperature	Defines the threshold from which an alarm signal will be generated to indicate the internal temperature is too low	-12.0 °C	-400 to 1000 (-40.0 °C to 100.0 °C)	The value must be at least 10.0 °C lower than the set value for the max. alarm threshold.		
	2	16–31	RW	16 bits	int:16	Yes	Yes	P90	R/W	Alarm threshold for max. internal temperature	Defines the threshold from which an alarm signal will be generated to indicate the internal temperature is too high	70.0 °C	-400 to 1000 (-40.0 °C to 100.0 °C)	The value must be at least 10.0 °C higher than the set value for the min. alarm threshold.		

IO-Link parameter								GEMÜ app parameter number	GEMÜ app access	Parameter name	Parameter de- scription	Default setting	Selection values	Description	IO-Link menu	GEMÜ app menu
Index	Sub-index	Bit	Access rights	Length	Data type	Data stor- age	Back-to- Box									
HEX	DEZ															
	3	32–47	RW	16 bits	uint:16	Yes	Yes	P91	R/W	Alarm threshold for min. internal humidity	Defines the threshold from which an alarm signal will be generated to in- dicate the in- ternal humidity is too low	0.0%	0 to 1000 (0.0% to 100.0%)	The value must be at least 5.0% smaller than the set value for the max. alarm threshold.		
	4	48–63	RW	16 bits	uint:16	Yes	Yes	P92	R/W	Alarm threshold for max. internal humidity	Defines the threshold from which an alarm signal will be generated to in- dicate the in- ternal humidity is too high	100.0%	0 to 1000 (0.0% to 100.0%)	The value must be at least 5.0% larger than the set value for the min. alarm threshold.		
	5	64–79	RW	16 bits	uint:16	Yes	Yes	P95	R/W	Alarm threshold for high oscilla- tions	Defines the threshold above which an alarm signal will be generated to in- dicate the oscil- lations are too high	0.0%	0 to 1000 (0.0% to 100.0%)			
	6	80–95	RW	16 bits	uint:16	Yes	Yes	P93	R/W	Alarm threshold for min. internal pressure	Defines the threshold from which an alarm signal will be generated to in- dicate the in- ternal pressure is too low	500 mbar	260 to 1260 (260 mbar to 1260 mbar)	The value must be at least 100 mbar smal- ler than the set value for the max. alarm threshold.		
	7	96–111	RW	16 bits	uint:16	Yes	Yes	P94	R/W	Alarm threshold for max. internal pressure	Defines the threshold from which an alarm signal will be generated to in- dicate the in- ternal pressure is too high	1230 mbar	260 to 1260 (260 mbar to 1260 mbar)	The value must be at least 100 mbar larger than the set value for the min. alarm threshold.		
	8	112– 119	RW	8 bits	uint:8	Yes	Yes	P96	R/W	Alarm threshold for min. control pressure	Defines the threshold below which an alarm signal will be generated to in- dicate the con- trol air supply pressure is too low	1.0 bar	0 to 100 (0.0 bar to 10.0 bar)	The value must be at least 0.5 bar lower than the set value for the max. alarm threshold.		

IO-Link parameter								GEMÜ app parameter number	GEMÜ app access	Parameter name	Parameter de- scription	Default setting	Selection values	Description	IO-Link menu	GEMÜ app menu
Index	Su- bindex	Bit	Access rights	Length	Data type	Data stor- age	Back-to- Box									
HEX	DEZ															
	9	120–127	RW	8 bits	uint:8	Yes	Yes	P95	R/W	Alarm threshold for max. control pressure	Defines the threshold above which an alarm signal will be generated to indicate the supply pressure of the control air is too high	7.1 bar	0 to 100 (0.0 bar to 10.0 bar)	The value must be at least 0.5 bar greater than the set value for the min. alarm threshold.		
0x00B0	0		RW	2 bytes	RecordT	Yes				Control parameters ¹⁾					Parameters Controller settings	Settings Controller settings
	1	0–15	RW	16 bits	unit:16	Yes	Yes	P23	RW	Proportional amplification ¹⁾	Defines the proportional amplification of the positioner	1.0	1 to 1000 (0.1 to 100.0%) (Setting value is re-determined and adjusted with each initialization)	The optimal value is automatically determined during initialization.		
0x00B1	0		RW	3 bytes	RecordT	Yes			RW	Dead zone ¹⁾					Parameters Controller settings	Settings Controller settings
	1	0–7	RW	8 bits	unit:8	Yes	Yes	P20	RW	Manual dead zone ¹⁾	Defines the permissible system deviation of the dead zone	1.0%	1 to 250 (0.1 to 25.0%)			
	2	8–15	RO	8 bits	unit:8	No	No	P44	RO	Automatic dead zone ¹⁾	Shows the automatically determined dead zone	1.0%	1 to 250 (0.1 to 25.0%)			
	3	16	RW	1 bit	Boolean	Yes	Yes	P24	RW	Dead zone adjustment ¹⁾	Activates/deactivates the automatic dead zone adjustment	0 (manual)	0 Manual	Manual adjustment with the parameter “Manual dead zone”		
													1 Auto	Automatic adjustment of the height based on the measured initialization operating times		
0x00B2	0		RW	4 bytes	RecordT	Yes			RW	Close tight function ¹⁾					Parameters Controller settings Close tight function	Settings Controller settings
	1	0–15	RW	16 bits	unit:16	Yes	Yes	P19	RW	Close tight function OPEN ¹⁾	Defines the lower range of the close tight function	99.5%	800 to 1000 (80.0 to 100.0%)	The function is deactivated with a setting of 100.0.		
	2	16–31	RW	16 bits	unit:16	Yes	Yes	P18	RW	Close tight function CLOSED ¹⁾	Defines the upper range of the close tight function	0.5%	0 to 200 (0 to 20.0%)	The function is deactivated with a setting of 0.0.		
0x00B4	0		RW	4 bytes	RecordT	Yes			RW	Split range ¹⁾					Parameters Controller settings Signal split	Settings Controller settings

IO-Link parameter								GEMÜ app parameter number	GEMÜ app access	Parameter name	Parameter de- scription	Default setting	Selection values		Description	IO-Link menu	GEMÜ app menu
Index	Su- bindex	Bit	Access rights	Length	Data type	Data stor- age	Back-to- Box										
HEX	DEZ																
	1	0–15	RW	16 bits	unit:16	Yes	Yes	P01	RW	Split range start ¹⁾	Defines the starting point of the split-range function	0.0%	0 to 900 (0 to 90.0%)		The value must be at least 10.0% lower than “Split range end”		
	2	16–31	RW	16 bits	unit:16	Yes	Yes	P02	RW	Split range end ¹⁾	Defines the end point of the split-range function	100%	100 to 1000 (10.0 to 100.0%)		The value must be at least 10.0% higher than “Split range start”		
0x00B6	0		RW	4 bytes	RecordT	Yes			RW	Position limitation ¹⁾						Parameters Application settings Stroke limiter/seal adjuster	Settings Application settings
	1	0–15	RW	16 bits	unit:16	Yes	Yes	P17	RW	Opening limiter ¹⁾	Defines the upper valve position as a limitation in the open direction	100.0%	100 to 1000 (10.0 to 100.0%)		The value must be at least 10.0% higher than “Seal adjuster”		
	2	16–31	RW	16 bits	unit:16	Yes	Yes	P18	RW	Seal adjuster ¹⁾	Defines the lower valve position as a limitation in the closed direction	0.0%	0 to 900 (0 to 90.0%)		The value must be at least 10.0% lower than “Opening limiter”		
0x00B8	0		RW	1 byte	RecordT	Yes			RW	Set value direction of action ¹⁾						Parameters Controller settings	Settings Controller settings
	1	0	RW	1 bit	Boolean	Yes	Yes	P15	RW	Set value direction of action	Defines the direction of action of the set value signal	0 (rising)	0	Rising	Valve opens when signal rises		
													1	Falling	Valve closes when signal rises		
0x00BC	0		RW	23 bytes	RecordT	Yes				Characteristic ¹⁾					Characteristic curve setting	Parameters Controller settings Characteristic curve setting	Settings Controller settings
	1	0–15	RW	16 bits	uint:16	Yes	Yes	P03	RW	Characteristic curve point 0% ¹⁾	Defines the calibration point at 0% set value of the free characteristic	0.0%	0 to 1000 (0 to 100.0%)		Assignment of the freely definable calibration points		
	2	16–31	RW	16 bits	uint:16	Yes	Yes	P04	RW	Characteristic curve point 10% ¹⁾	Defines the calibration point at 10% set value of the free characteristic	10.0%	0 to 1000 (0 to 100.0%)				
	3	32–47	RW	16 bits	uint:16	Yes	Yes	P05	RW	Characteristic curve point 20% ¹⁾	Defines the calibration point at 20% set value of the free characteristic	20.0%	0 to 1000 (0 to 100.0%)				

IO-Link parameter								GEMÜ app parameter number	GEMÜ app access	Parameter name	Parameter de- scription	Default setting	Selection values		Description	IO-Link menu	GEMÜ app menu
Index	Su- bindex	Bit	Access rights	Length	Data type	Data stor- age	Back-to- Box										
HEX	DEZ																
	4	48–63	RW	16 bits	uint:16	Yes	Yes	P06	RW	Characteristic curve point 30% ¹⁾	Defines the cal- ibration point at 30% set value of the free charac- teristic	30.0%	0 to 1000 (0 to 100.0%)				
	5	64–79	RW	16 bits	uint:16	Yes	Yes	P07	RW	Characteristic curve point 40% ¹⁾	Defines the cal- ibration point at 40% set value of the free charac- teristic	40.0%	0 to 1000 (0 to 100.0%)				
	6	80–95	RW	16 bits	uint:16	Yes	Yes	P08	RW	Characteristic curve point 50% ¹⁾	Defines the cal- ibration point at 50% set value of the free charac- teristic	50.0%	0 to 1000 (0 to 100.0%)				
	7	96– 111	RW	16 bits	uint:16	Yes	Yes	P09	RW	Characteristic curve point 60% ¹⁾	Defines the cal- ibration point at 60% set value of the free charac- teristic	60.0%	0 to 1000 (0 to 100.0%)				
	8	112– 127	RW	16 bits	uint:16	Yes	Yes	P10	RW	Characteristic curve point 70% ¹⁾	Defines the cal- ibration point at 70% set value of the free charac- teristic	70.0%	0 to 1000 (0 to 100.0%)				
	9	128– 143	RW	16 bits	uint:16	Yes	Yes	P11	RW	Characteristic curve point 80% ¹⁾	Defines the cal- ibration point at 80% set value of the free charac- teristic	80.0%	0 to 1000 (0 to 100.0%)				
	10	144– 159	RW	16 bits	uint:16	Yes	Yes	P12	RW	Characteristic curve point 90% ¹⁾	Defines the cal- ibration point at 90% set value of the free charac- teristic	90.0%	0 to 1000 (0 to 100.0%)				
	11	160– 175	RW	16 bits	uint:16	Yes	Yes	P13	RW	Characteristic curve point 100% ¹⁾	Defines the cal- ibration point at 100% set value of the free char- acteristic	100.0%	0 to 1000 (0 to 100.0%)				
	12	176– 178	RW	16 bits	uint:16	Yes	Yes	P14	RW	Control charac- teristic ¹⁾	Defines the con- trol character- istic	0 (linear)	0	Linear	Linear control characteristic		

IO-Link parameter								GEMÜ app parameter number	GEMÜ app access	Parameter name	Parameter de- scription	Default setting	Selection values		Description	IO-Link menu	GEMÜ app menu
Index	Su- bindex	Bit	Access rights	Length	Data type	Data stor- age	Back-to- Box										
HEX	DEZ																
													1	Free character- istic	Free control characteristic. The control characteristic can be specified via eleven ad- justable calibra- tion points, which define the correlation between the set value and valve position. A linear curve is used for control between the calibration points.		
¹⁾ The parameter is only relevant in the positioner device function ²⁾ The device is restarted automatically when the device function is changed. The process valve is vented for the duration of the restart. ³⁾ Adjustment facility only possible with positioner device version order version (code C) ⁴⁾ Only OPEN/CLOSE actuation device function																	

19 Troubleshooting

Three different message categories are distinguished between in the device, which suggest faults due to internal or external influences. These are made visible by the high-visibility LEDs and output via the electrical interfaces.

Error: The device can no longer properly carry out its functionality. It is imperative that the cause of the error be corrected for continued operation. The set error position ("Error position" parameter) is performed.

Error2: The device can no longer properly carry out its functionality. It is imperative that the cause of the error be corrected for continued operation. The process valve is vented.

Warning: A warning does not affect the operating mode of the device; however, under certain circumstances, it may not carry out the required function. We recommend checking the cause and, if necessary, correcting it.

Information: The status of a temporary function is displayed.

Error message	IO-Link mode	Cat-egory	IO-Link event code	"Message ID GEMÜ App"	Relev-ant error time*	Dia-gnostic mes-sage**	Description	Description of measures
Not calibrated	Appear/Disappear	Error	0x8CA9	1	No	No	The product is not calibrated.	Please send the product to GEMÜ for repair work. To accomplish this, contact your GEMÜ contact person. Further information on this can be found via the product overview in the GEMÜ App under "Maintenance".
Not initialized	Appear/Disappear	Warn-ing	0x8CAA	2	No	No	The product is not initialized.	- Carry out initialization. - During activated autonomous detection of end positions, both valve end positions must be approached once. - In the classic detection of end positions mode, initialization must be started manually. This can, for instance, be carried out via the button on the product overview in the GEMÜ App. Alternatively, please observe the information in the "Commissioning" chapter of the operating instructions.
End position displacement OPEN	Single shot	Inform-ation	0x8CAB	3	No	No	Autonomous de-tection of end positions recognizes and updates a displacement of the OPEN end position.	No measures required.
End position displacement CLOSED	Single shot	Inform-ation	0x8CAC	4	No	No	Autonomous de-tection of end positions recognizes and updates a displacement of the CLOSED end position.	No measures required.

Error message	IO-Link mode	Cat-egory	IO-Link event code	"Message ID GEMÜ App"	Relev-ant error time*	Dia-gnostic mes-sage**	Description	Description of measures
Duration error in the OPEN direction	Appear/Disappear	Warn-ing	0x8CC4	28	No	Yes	The OPEN end position of the process valve has been reached, but not within the expected time.	- Ensure that there is an adequate compressed air supply. - Check the pneumatic connections. - Check the pneumatic connection points. - Test the performance of the valve.
Duration error in the CLOSED direction	Appear/Disappear	Warn-ing	0x8CC5	29	No	Yes	The CLOSED end position of the process valve has been reached, but not within the expected time.	- Ensure that there is an adequate compressed air supply. - Check the pneumatic connections. - Check the pneumatic connection points. - Test the performance of the valve.
No movement, or incorrect movement	Appear/Disappear	Warn-ing	0x8CC6	30	No	Yes	No change in the process valve position can be detected within the permissible time	- Ensure that there is an adequate compressed air supply. - Check the pneumatic connections. - Check the pneumatic connection points. - Test the performance of the valve.
No movement or incorrect movement in the OPEN direction	Appear/Disappear	Warn-ing	0x8CC7	31	No	Yes	The OPEN end position of the process valve is not reached.	- Ensure that there is an adequate compressed air supply. - Check the pneumatic connections. - Check the pneumatic connection points. - Test the performance of the valve.
No movement or incorrect movement in the CLOSED direction	Appear/Disappear	Warn-ing	0x8CC8	32	No	Yes	The CLOSED end position of the process valve is not reached.	- Ensure that there is an adequate compressed air supply. - Check the pneumatic connections. - Check the pneumatic connection points. - Test the performance of the valve.

Error message	IO-Link mode	Cat-egory	IO-Link event code	"Message ID GEMÜ App"	Relev-ant error time*	Dia-gnostic mes-sage**	Description	Description of measures
Travel sensor error	Appear/Disappear	Error2	0x8CA3	60	No	No	It is not possible to read in a valid signal from the travel sensor.	- Ensure that the mechanical assembly on the valve is correct. - Check all connecting components (e.g. mounting kits, etc.) between the valve and product to ensure that they are being used correctly and in their entirety. - If errors persist, please send the product to GEMÜ for repair work. To accomplish this, contact your GEMÜ contact person. Further information on this can be found via the product overview in the GEMÜ App under "Maintenance".
Travel sensor maximum value exceeded	Appear/Disappear	Warn-ing	0x8CA4	62	No	No	The travel sensor delivers values above the maximum valid range.	- Ensure that the mechanical assembly on the valve is correct. - Check all connecting components (e.g. mounting kits, etc.) between the valve and product to ensure that they are being used correctly and in their entirety.
Travel sensor minimum value not reached	Appear/Disappear	Warn-ing	0x8CA5	63	No	No	The travel sensor delivers values below the minimum valid range.	- Ensure that the mechanical assembly on the valve is correct. - Check all connecting components (e.g. mounting kits, etc.) between the valve and product to ensure that they are being used correctly and in their entirety.
Valve activations alarm threshold reached	Appear/Disappear	Warn-ing	0x8CEE	70	No	No	The number of valve actuations set in the "Valve actuations user counter warning threshold" parameter has been reached.	- Check the condition of the wearing parts of the valve. Further information on this can be found via the product overview in the GEMÜ App under "Maintenance". - If the condition is faultless, the warning threshold in the "Valve actuations user counter warning threshold" parameter can be adapted as an alternative.

Error message	IO-Link mode	Cat-egory	IO-Link event code	"Message ID GEMÜ App"	Relev-ant error time*	Dia-gnostic mes-sage**	Description	Description of measures
Valve actuations counter reset	Single shot	Inform-ation	0x8CEF	71	No	No	The counter for the valve actuations has been reset. The message is independently acknowledged after 30 seconds.	No measures required.
Switching cycles alarm threshold reached	Appear/Disappear	Warn-ing	0x8CF0	72	No	No	The number of switching cycles set in the "User switching cycles warning threshold" parameter has been reached.	- Check the condition of the wearing parts of the valve. Further information on this can be found via the product overview in the GEMÜ App under "Maintenance". - If the condition is faultless, the warning threshold in the "User switching cycles warning threshold" parameter can be adapted as an alternative.
Switching cycle counter reset	Single shot	Inform-ation	0x8CF1	73	No	No	The user switching cycle counter has been reset. The message is independently acknowledged after 30 seconds.	No measures required.
Control air supply pressure exceeded	Appear/Disappear	Error2	0x8D0C	100	No	No	The maximum permissible control pressure has been exceeded	Reduce the control air supply pressure on the product. Unacceptably high control pressures can permanently damage or destroy the product.
Control pressure alarm threshold exceeded	Appear/Disappear	Warn-ing	0x8D0D	101	Yes	No	The maximum control pressure as set in the "Max. control pressure alarm threshold" parameter has been reached or exceeded.	Reduce the applied control air supply pressure. Alternatively, check the maximum permissible control pressure of the process valve. If this is above the set value in the "Max. control pressure alarm threshold" parameter, this can be increased.
Control pressure alarm threshold not reached	Appear/Disappear	Warn-ing	0x8D0E	102	Yes	No	The minimum control pressure as set in the "Min. control pressure alarm threshold" parameter has been reached or undershot	Increase the applied control air supply pressure. Alternatively, check the minimum permissible control pressure of the process valve. If this is below the set value in the "Min. control pressure alarm threshold" parameter, this value can be decreased.

Error message	IO-Link mode	Cat-egory	IO-Link event code	"Message ID GEMÜ App"	Relev-ant error time*	Dia-gnostic mes-sage**	Description	Description of measures
Minimum control pressure not reached	Appear/Disappear	Error2	0x8D0F	103	No	No	The minimum permissible control air supply pressure has not been reached	Check the control air supply line and the pneumatic connection.
Critical supply voltage	Appear/Disappear	Error	0x8D15	109	No	No	The maximum permissible supply voltage has been exceeded	Check the power source to ensure that the output voltage has been selected and set correctly. Ensure the power supply is within the permissible range.
Supply voltage exceeded	Appear/Disappear	Warn-ing	0x8D16	110	Yes	No	The maximum permissible supply voltage will be exceeded soon	Check the power source to ensure that the output voltage has been selected and set correctly. Ensure the power supply is within the permissible range.
Supply voltage not reached	Appear/Disappear	Error	0x8D17	111	No	No	The minimum permissible supply voltage has not been reached	Check the power source to ensure that the output voltage has been selected and set correctly. Ensure the power supply is within the permissible range.
Internal temperature exceeded	Appear/Disappear	Error	0x8D1E	118	No	No	The maximum permissible internal temperature has been exceeded	Reduce the ambient temperature at the product's installation site or establish cooler conditions.
Internal temperature has not been reached	Appear/Disappear	Error	0x8D1F	119	No	No	The minimum permissible internal temperature has not been reached	Increase the ambient temperature at the product's installation site or establish warmer conditions.
Internal temperature alarm threshold exceeded	Appear/Disappear	Warn-ing	0x8D20	120	Yes	No	The maximum temperature as set in the "Max. internal temperature alarm threshold" parameter has been reached or exceeded.	Reduce the ambient temperature at the product's installation site or establish cooler conditions. Alternatively, check the maximum permissible temperature range of the product. If this is above the set value in the "Max. internal temperature alarm threshold" parameter, this can be increased.
Internal temperature alarm threshold has not been reached	Appear/Disappear	Warn-ing	0x8D21	121	Yes	No	The minimum temperature as set in the "Min. internal temperature alarm threshold" parameter has been reached or undershot.	Increase the ambient temperature at the product's installation site or establish warmer conditions. Alternatively, check the minimum permissible temperature range of the product. If this is below the set value in the "Min. internal temperature alarm threshold" parameter, this can be reduced.

Error message	IO-Link mode	Cat-egory	IO-Link event code	"Message ID GEMÜ App"	Relev-ant error time*	Dia-gnostic mes-sage**	Description	Description of measures
Internal humid-ity alarm threshold ex-ceeded	Appear/Disap-pear	Warn-ing	0x8D22	122	Yes	No	The maximum hu-midity as set in the "Max. internal hu-midity alarm threshold" pa-rameter has been reached or ex-ceeded.	- Check that the product housing is fully intact and sealed and that all seals are seated correctly. - Reduce the humidity at the product's installation site or establish drier conditions. Alternatively, check the max-imum permissible humidity range of the product. If this is above the set value in the "Max. internal humidity alarm threshold" parameter, this can be increased.
Internal humid-ity alarm threshold not reached	Appear/Disap-pear	Warn-ing	0x8D23	123	Yes	No	The minimum hu-midity as set in the "Min. internal hu-midity alarm threshold" pa-rameter has been reached or under-shot.	Increase the humidity at the product's installation site or establish more humid condi-tions. Alternatively, check the minimum permissible humidity range of the product. If this is below the set value in the "Min. in-ternal humidity alarm threshold" parameter, this can be reduced.
Internal pres-sure alarm threshold ex-ceeded	Appear/Disap-pear	Warn-ing	0x8D24	124	Yes	No	The maximum in-ternal pressure as set in the "Max. in-ternal pressure alarm threshold" parameter has been reached or exceeded.	- Check the product for in-ternal leakages. - Check the height above sea level at the product's install-ation site. Alternatively, check the maximum per-missible internal pressure/ height above sea level of the product. If this is above the set value in the "Max. in-ternal pressure alarm threshold" parameter, this can be increased.
Internal pres-sure alarm threshold not reached	Appear/Disap-pear	Warn-ing	0x8D25	125	Yes	No	The minimum in-ternal pressure as set in the "Min. in-ternal pressure alarm threshold" parameter has been reached or undershot.	Check the height above sea level at the product's install-ation site. Alternatively, check the minimum per-missible internal pressure/ height above sea level of the product. If this is below the set value in the "Min. in-ternal pressure alarm threshold" parameter, this can be reduced.

Error message	IO-Link mode	Cat-egory	IO-Link event code	"Message ID GEMÜ App"	Relev-ant error time*	Dia-gnostic mes-sage**	Description	Description of measures
Vibration alarm threshold exceeded	Appear/Disappear	Warn-ing	0x8D2A	130	Yes	No	The maximum vibration level as set in the "Alarm threshold for high oscillations" parameter has been reached or exceeded.	- Check the product's installation conditions, specifically for loose screws, fastening components and pipeline fixture mounts. - Check the flow velocity in the piping and, if possible, reduce it. - Check the suitability of the process valve for the prevailing operating parameters.
Warning message memory	Appear/Disappear	Warn-ing	0x8D70	200	No	No	The memory currently cannot be accessed.	Please send the product to GEMÜ for repair work. To accomplish this, contact your GEMÜ contact person. Further information on this can be found via the product overview in the GEMÜ App under "Maintenance".
Internal device error	Appear/Disappear	Error	0x5000	201	No	No	An error has occurred in the unit.	Please send the product to GEMÜ for repair work. To accomplish this, contact your GEMÜ contact person. Further information on this can be found via the product overview in the GEMÜ App under "Maintenance".
Fieldbus communication error	Appear/Disappear	Error	0x8D75	205	Yes	No	The fieldbus communication was aborted.	Fieldbus communication is expected. Check that the communications interface has been wired and configured correctly.
Invalid process data	Appear/Disappear	Error	-	206	Yes	No	The process data has been set to invalid by the master ("Process Data Output invalid").	The process data marked as invalid by the master triggers an error on the device, which reacts accordingly. Check the master configuration with regard to the status of the process data ("Process Data output validity state").

Error message	IO-Link mode	Cat-egory	IO-Link event code	"Message ID GEMÜ App"	Relev-ant error time*	Dia-gnostic mes-sage**	Description	Description of measures
Initialization error (Event is only triggered if initialization was started via IO-Link process data)	Single shot	Inform-ation	0x8DA2	250	No	No	During initializa-tion, an error oc-curred which caused it to be ter-minated	- Ensure that the mechanical assembly on the valve is correct. - Check all connecting components (e.g. mounting kits, etc.) between the valve and product to ensure that they are being used correctly and in their entirety. - Ensure that there is an adequate compressed air supply. - Check the pneumatic connections. - Check the pneumatic connection points. - Test the performance of the valve.

* For error time-relevant messages, a delay time can be set between error detection and response using the "Error time" parameter.

** Diagnostic messages can be activated/deactivated together using the associated "Diagnostic messages" parameter.

20 ISDU errors

This table describes the error codes that can be reported back via the ISDU in the event of incorrect parameterization.

Designation	Error code	Additional code	Description
Index not available	0x80	0x11	Read or write access to a non-existent index.
Subindex not available	0x80	0x12	Read or write access to a non-existent subindex.
Service temporarily not available	0x80	0x20	Read or write access to a parameter is not possible due to the current status of the application.
Service temporarily not available – local control	0x80	0x21	Read or write access to a parameter is not possible due to a local operation on the application, e.g. parameterization via an integrated control panel of the device.
Service temporarily not available – Devicecontrol	0x80	0x22	Read or write access to a parameter is not possible due to a "remote status" of the device, e.g. parameterization via remote access
Access denied	0x80	0x23	Write access to a parameter that can only be read.
Parameter value out of range	0x80	0x30	Write access to a parameter where the parameter value is outside the permitted limits.
Parameter value above limit	0x80	0x31	Write access to a parameter where the parameter value is above the defined limit.
Parameter value below limit	0x80	0x32	Write access to a parameter where the parameter value is below the defined limit.

Designation	Error code	Additional code	Description
Parameter length overrun	0x80	0x33	Write access to a parameter where the parameter length is greater than the defined length. This is used, for example, if the data object is too large to be processed by the application.
Parameter length underrun	0x80	0x34	Write access to a parameter where the parameter length is less than the defined length. This is used, for example, if the data object is too small to be processed by the application.
Function not available	0x80	0x35	Write access to a command that is not supported by the application, e.g. a system command that is not supported.
Function temporarily not available	0x80	0x36	Write access to a command that is not supported by the application at this point in time, e.g. a system command that is not currently supported.
Invalid Parameter Set	0x80	0x40	This error is used if a value is transmitted during an individual transmission of ISDU parameters that is non-compliant with another parameter setting.
Inconsistent Parameter Set	0x80	0x41	This error is sent at the end of a download of a block parameter transfer if there is an error in the parameter set, e.g. if there are discrepancies.
Application not ready	0x80	0x82	Read or write access if the application is not available.

21 Inspection and maintenance

WARNING



The equipment is subject to pressure!

- ▶ Risk of severe injury or death
- Depressurize the plant or plant component.
- Completely drain the plant or plant component.

NOTICE

Faulty sealing rings or O-rings!

- ▶ Sudden pressure increase in the product housing due to leakage at the stud bolt sealing ring or pressure sensor O-ring
- Carry out product maintenance regularly and pay attention to the integrity of the sealing rings.

NOTICE

Exceptional maintenance work!

- ▶ Damage to the GEMÜ product
- Any maintenance work and repairs not described in these operating instructions must not be performed without consulting the manufacturer first.

The operator must carry out regular visual examinations of the products, depending on the operating conditions and the potentially hazardous situations, in order to prevent leakage and damage.

1. Have servicing and maintenance work performed by trained personnel.
2. Wear appropriate protective gear as specified in the plant operator's guidelines.
3. Disconnect from power supply.
4. Shut off plant or plant component.
5. Secure plant or plant component against recommissioning.
6. Depressurize the plant or plant component.
7. Actuate products that are always in the same position four times a year.

21.1 Spare parts

No spare parts are available for this product. If it is faulty, please return it to GEMÜ for repair.

21.2 Cleaning the product

- Clean the product with a damp cloth.
- Do **not** clean the product with a high pressure cleaning device.

22 Disassembly

22.1 Combi switchbox disassembly

WARNING



Possible risk of crushing by the indicator spindle!

- ▶ Injury possible, because the actuator must be pressurised in order to reach the flat (only NC drives).
- Do not reach into the operating range of the indicator spindle.

NOTICE

- ▶ Do not unscrew the stud bolts 3 and 8 too far or pull them upwards because the sealing washers 5 could come loose and fall down.
- Unscrew the stud bolts alternately (left/right) until the product can be removed from the actuator.

NOTICE

It is possible to touch the electronic system when the product is dismantled!

- When disassembling the product, disconnect the power supply.

NOTICE

The pneumatic connections also act as a fixture to the actuator!

- Before performing any work on the product, depressurize the pneumatic connection.

1. Disassemble in reverse order to assembly.
2. Unscrew the electrical wiring.
3. Disassemble the product. Observe warning notes and safety information.

22.2 Type E1B0 Bluetooth module disassembly

Observe the separate documentation for the type E1B0 Bluetooth module.

CAUTION



Hot components!

- ▶ Burns from heated components in conjunction with the ambient temperature
- Only work on a plant that has cooled down or with appropriate protective gear.

⚠ CAUTION**Risk of crushing!**

- ▶ Pinching of fingers during disassembly/installation of the type E1B0 Bluetooth module in the slider cover or of the type E1B0 Bluetooth module with a slider cover in the housing
- Installation work must only be performed by trained personnel.
- Wear suitable protective gear.

⚠ CAUTION**Risk of cutting injuries!**

- ▶ Risk of cutting injuries due to sharp edges, corners or protruding parts
- Installation and disassembly work must only be performed by trained personnel.
- Use suitable cutting protection.

⚠ CAUTION**Minor or moderate injury from a falling product!**

- ▶ The type E1B0 Bluetooth module may fall out of the housing if, for example, the snap-in function is defective and the product is installed overhead.
- Check all parts for visual damage.
- If necessary, take safety measures and wear appropriate protective gear.
- Cordon off the work area in the plant to ensure that no one can pass through below the product.


NOTICE**Damage to the product!**

- Ensure that the module is installed/disassembled correctly and pay attention to any damage to the product.



1. Disassemble in reverse order to assembly.
2. Disassemble the product. Observe warning notes and safety information.

22.2.1 Removing the type E1B0 Bluetooth module


Check all parts for damage, contaminants and moisture prior to disassembly.




1. Undo the screw 1 (hexagon socket, size 1.5) of the slider cover 2 (the screw is secured against falling out of the slider cover 2 by a circlip).



2. Remove the slider cover 2 with the screw 1 from the housing 4.



3. Undo the snap hook 5 of the slider cover 2 and use your index finger to pry the type E1B0 Bluetooth module 3 through the recessed handle 6 and out of the slider cover 2 (do not use a tool as this may cause damage!).



4. Remove the type E1B0 Bluetooth module **3** from the slider cover **2**.
5. Reinstall the slider cover **2** in order to seal the housing of the device **4** (size 1.5 hexagon socket, maximum torque 0.4 Nm/hand tight).
6. Store or dispose of the type E1B0 Bluetooth module properly.

23 Disposal

1. Pay attention to adhered residual material and gas diffusion from penetrated media.
2. Dispose of all parts in accordance with the disposal regulations/environmental protection laws.
3. Dispose of electronic components separately.

24 Returns

Legal regulations for the protection of the environment and personnel require that the completed and signed return delivery note is included with the dispatch documents. Returned goods can be processed only when this note is completed. If no return delivery note is included with the product, GEMÜ cannot process credits or repair work but will dispose of the goods at the operator's expense.

1. Clean the product.
2. Request a return delivery note from GEMÜ.
3. Complete the return delivery note.
4. Send the product with a completed return delivery note to GEMÜ.

25 EU Declaration of Conformity

Version 1

**EU-Konformitätserklärung**
EU Declaration of Conformity

Wir, die Firma

We, the company

GEMÜ Gebr. Müller Apparatebau GmbH & Co. KG
Fritz-Müller-Straße 6-8
74653 Ingelfingen
Deutschland

erklären hiermit in alleiniger Verantwortung, dass die nachfolgend bezeichneten Produkte den Vorschriften der genannten Richtlinien entspricht.

hereby declare under our sole responsibility that the below-mentioned products complies with the regulations of the mentioned Directives.

Produkt: GEMÜ 44A0**Product:** GEMÜ 44A0**Produktname:** Multifunktionale Ventilansteuerung**Product name:** Multi-functional valve actuation**Richtlinien:****Guidelines:**

EMC 2014/30/EU

Folgende harmonisierte Normen (oder Teile hieraus) wurden angewandt:**The following harmonized standards (or parts thereof) have been applied:**

EN 61000-6-2:2005/AC:2005; EN 61000-6-3:2007/A1:2011/AC:2012

Weitere angewandte Normen:**Further applied norms:**

EN IEC 61131-9:2022

i.V. M. Barghoorn
Leiter Globale Technik
Ingelfingen, 10.04.2025GEMÜ Gebr. Müller Apparatebau GmbH & Co. KG
Fritz-Müller-Straße 6-8, 74653 Ingelfingen, Deutschlandwww.gemu-group.com
info@gemu.de



GEMÜ Gebr. Müller Apparatebau GmbH & Co. KG
Fritz-Müller-Straße 6-8, 74653 Ingelfingen-Criesbach, Germany
Phone +49 (0) 7940 1230 · info@gemue.de
www.gemu-group.com

Subject to alteration

12.2025 | 88946414